Spirit X399-AS User Guide



Revision 1.0 August 2018

Please Read This First

Thank you for buying a Northern Micro Spirit X399-AS computer. Northern Micro is committed to providing our customers with the best value on the market today. This means building the systems that meet your specific needs and supporting you with any issues that you may encounter.

All Northern Micro Spirit computers are assembled and tested in our manufacturing facility in Ottawa. A full Service & Support *network* across Canada stands behind every Spirit system we build.

The computer you have purchased is optimized for today's Operating Systems and applications; however, in the future, you may come upon situations that demand greater processing power or speed. Thanks to the latest advances in computer *hardware* technology, your Spirit X399-AS is completely upgradable. Contact your Northern Micro Sales or Service representative for advice on how to upgrade your computer should the need arise.

The Spirit X399-AS is <u>Energy Star</u> and <u>Epeat</u> Gold certified. These environmental standards ensure that the computer can take advantage of energy saving features. Your Spirit X399-AS is designed to run in sleep mode when user inactivity reaches 30 minutes. Your *monitor* is designed to run in display sleep mode when user inactivity reaches 15 minutes. You can "wake up" the computer or display by moving the *mouse* or by hitting any key on the keyboard. If connected to a *network*, Wake-on-LAN features can be enabled to allow *network* administrators to wake up the computer remotely or on a given schedule. The Spirit X399-AS is certified to meet power management criteria of the Microsoft logo program and is equipped with an <u>80 Plus</u> Platinum power supply.

This manual has been prepared for both advanced and novice users. You will find general PC information as well as detailed specifications about the system you have purchased.

• Northern Micro Sales and Service & Support Departments may be reached at: 1-800-563-1007.

<u>Northern Micro</u> is one of Canada's leading *hardware* integrators and custom manufacturers of mid-range and high-end PCs and workstations.

Our mission is to provide customized high quality computer *hardware* products and services to meet the advanced technical needs of highly knowledgeable customers who seek to maximize their productivity.

To be fully responsive to our customers' wants and needs, we also:

- carry brand name computer products;
- supply network peripheral equipment and multi-media products;
- supply server / storage and printing solutions.

Through all facets of the operation, we are driven by our quality philosophy.

Northern Micro's quality policy, communicated within and beyond the corporation, reads as follows:

"Northern Micro is committed to delivering the ultimate customer satisfaction by providing reliable, innovative and flexible computing solutions and by continuously improving our product and service offerings".

In essence, Northern Micro, its management and its employees strive to be their customers' personal computer *hardware* specialists. Northern Micro's focus is on quality and customer satisfaction, and to provide products and services in complementary areas of specialization. We strongly believe in treating customers as members of our own family.

Additionally read our **Privacy Statement**.

Energy Star®

The Northern Micro Spirit X399-AS is certified to meet Energy Star requirements. ENERGY STAR is a voluntary program that helps businesses and individuals save money and protect our climate through superior energy efficiency. Governments around the world, including Canada's, have embraced the Energy Star program. Through its partnerships with 18,000 private and public sector organizations, ENERGY STAR delivers the technical information and tools that organizations and consumers need to choose energy-efficient solutions and best management practices.

An ENERGY STAR qualified computer delivers substantial savings over a conventional computer. Power management is important to saving energy, especially since computers are often in use more hours per day than they used to be. ENERGY STAR power management features place computers (CPU, hard drive, etc.) into a low-power "sleep mode" after a designated period of inactivity. Simply hitting a key on the keyboard or moving the *mouse* awakens the computer in a matter of seconds. Additionally, ENERGY STAR

qualified computers with networking capabilities have the ability to enable and disable Wake On LAN for Sleep mode, allowing greater use of low power modes without a loss of IT system maintenance capabilities.



Contact Us

Northern Micro Locations

Northern Micro is a Canada-wide operation with offices in Halifax, Quebec City and Ottawa.

Our headquarter and manufacturing plant are located in Ottawa.

National Service Center : 1-800-563-1007 extension 241

NM Ottawa

3155 Swansea Cr. Ottawa, Ontario K1G 3J3 Phone: (613) 226-1117 Fax: (613) 226-3810 Toll Free: 1 (800) 563-1007 info@nmico.ca

NM Halifax 102 Chain Lake Drive Suite 220 Halifax, NS B3S 1A7 Phone: (902) 422-9383 Fax: (902) 422-9384 halifax@nmicro.ca_

NM Québec

3107 ave des Hotels, Suite 24 Sainte-Foy, Québec G1W 4W5 Phone: (418) 654-1733 Fax: (418) 654-1744 Toll Free: 1 (877) 654-1733 quebec@nmicro.ca

On-Line Support

Northern Micro has been continuously investing time and resources to improve and provide you with a wide range of on-line support:

 The <u>Service and Support Site</u> where you can *download* the latest device drivers and *BIOS* upgrade; visit our PC Archives for specifications, manuals and; place service calls, etc.

Unpacking Your Computer

The Spirit X399-AS is packed with corrugated cardboard to keep it in place during transit. To unpack it follow these steps:

- Cut the tape holding the flaps and fold back the flaps
- Remove any accessories placed in the cardboard spacer insert. These may include cables, a plastic bag including manuals, DVDs, cables, small accessories and a mouse (if ordered).
- Lift out the cardboard spacer insert.
 - Lift out the inner cardboard box which covers the top half of the computer.
- Carefully slide the PC up out of the box.





• Save all cartons and packing material for future shipping and transportation.

• To repack the PC, reverse the above instructions.

Initial Computer Setup

Setting up your Computer

After unpacking your computer and checking all the items in the box, you can set up and start your computer.

- Set the computer on a flat space. Tower units can be put on their sides.
- Locate your *monitor* and computer in a dust-and-moisture-free area where there will be minimal glare on the screen.
- Connect the *monitor* cable to the video connector at the back of the computer.
- Connect the *mouse* and keyboard cables to the matching connectors at the back of the computer.
- Plug the *monitor* power cord into a dedicated electrical outlet or a surge-protected power bar.
- Plug the system power cord into the back of the system in the matching connector; then plug the cord into the power bar.

Starting up the Computer for the first time

Turn on the devices in the following order:

- 1. Monitor
- 2. External devices (USB or other)
- 3. System power

Front Panel



USB Ports

There are two (2) additional USB Port on the Front panel of the computer.

Audio Ports

For convenience there is 1 (one) Microphone port and 1 (one) stereo line out port on the front panel.

System power switch

The system power switch is located on the front of the case. You should always be certain that the power is turned off before modifying the *hardware* configuration in any way. Pushing the power switch for less than 4 seconds places the system into sleep mode (if enabled in Setup). When the power button is pressed for more than 4 seconds, the system enters the Soft-Off mode.

Indicator lights

These lights indicate the operation status of your computer.

Reset button

The reset button allows you to restart the system without turning the power off. If you encounter any problems while using unfamiliar *software*, you can always restart quickly from the *RAM* test stage by pressing the reset button. You will have to use a pen, pencil or other small object to press the Reset button. This feature was added to prevent accidental reset of the unit.



- Any data not saved to disk will be lost

The front panel gives access to power and reset switches, indicator light and front USB /audio.

Back Panel

The back panel has all the connections that lead from the system unit to external peripherals and the power source.





Turn off all power switches before connecting or disconnecting cables/wires!

- Ensure that cables/wires are attached to the peripheral device first and connect to the outlet unit later.
- Turn the system unit power switch off before you plug the power cable into an electrical outlet.

[•] See details on <u>Rear Panel Connectors</u>



Removing the Case Cover

1. Unlatch the cover and open the case from the back





2. Slide the side cover back

3. Lift the three tabs as illustrated and pull back the front bezel.

4. That opens the front of the case





Chassis Intrusion



• The <u>removal of the case cover</u> while the system is powered on will register a Chassis Intrusion Alert detected by the Chassis Intrusion lead on the motherboard.

The board supports a chassis security feature that detects if the chassis cover has been removed. The security feature uses a mechanical switch on the chassis that can be connected to the chassis intrusion header on the Desktop Board.



Power Supply Specs

850 Watts ATX Power Supply

EVGA 850GQ ATX Power Supply						
AC Input Rating	DC Output Rating					
AC Input: 100V - 240V	DC Output	+3.3V	+5V	+12V	-12V	+5Vsb
Current: 14A	Max Load	24A	24A	70.8A	0.5A	3.0A
Frequency: 60/50Hz	Maximum	120)W	849.6W	6W	15W
	Combined Wattage	Total Power: 850W@+50°C				

- Dimensions: 150mm (W) x 85mm(H) x 180mm(L)
 Safety Approvals CE, CB, FCC, TUV, CCC, RCM, RoHS, WEEE, cTUVus, BSMI, CCC



Optional Power Supply

500 Watts ATX Power Supply

Sparkle FSP500-60EGN ATX Power Supply							
AC Input Rating	DC Output Rating						
AC Input: 90V - 264V	DC Output	+3.3V	+5V	+12V1	+12V2	-12V	+5Vsb
Current: 3A - 6A	Max Load	24A	24A	18A	18A	0.3A	3.5A
Frequency: 47Hz - 63Hz	Maximum	130W 432W (36A) 21.1W			.1W		
	Combined Power	Tota	al Power	: 500W;	Peak P	ower: 58	50W

- Dimensions: 150mm (W) x 86mm(H) x 140mm(L)
 Safety Approvals UL/CUL, CE, CB, FCC Class B, TUV



Power Supply Removal

1. Remove the four screws supporting the power supply.



2. Gently slide the power supply out of position.



Final Power Connection Procedures

- 1. After all connections are made, close the system case cover.
- 2. Make sure that all switches are in the off position as marked by O.
- 3. Connect the power supply cord into the power supply located on the back of your system case as instructed by your system user's manual.
- 4. Connect the power cord onto a power outlet that is equipped by a *surge protector*.
- 5. You may then turn on your devices in the following order:
 - Monitor
 - External devices
 - System power
- 6. The power LED on the front panel of the system case will light, as will the *monitor* LED. The system will then run power-on tests. While the tests are running, additional messages will appear on the screen. If you do not see anything within 30 seconds from the time you turn on the power, the system may have failed a power-on test. Recheck your settings and connections or call Northern Micro for assistance.
- 7. During power-on, hold down the **DEL** key to enter **BIOS** setup.

Before you Proceed

Take note of the following precautions before you install motherboard components or change any motherboard settings.



- ⚠
- Unplug the power cord from the wall socket before touching any component.
- Use a grounded wrist strap or touch a safely grounded object or metal object, such as the power supply case, before handling components to avoid damaging them due to static electricity
- Hold components by the edges to avoid touching the ICs on them.
- Whenever you un-install any component, place it on a grounded anti-static pad or in the bag that came with the component.
- Before you install or remove any component, ensure that the ATX power supply is switched off or the power cord is detached from the power supply. Failure to do so may cause severe damage to the motherboard, peripherals, and/or components.
- Caution: There is a risk of explosion if the battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

Specifications Summary

Asus Desktop Motherboard Prime X399-A specifications summary

ADU	AMD SocketTR4 socket for AMD Ryzen [™] Threadripper [™] processors			
GPU	* Refer to <u>www.asus.com</u> for the CPU support list.			
Chipset	AMD X399			
	AMD Ryzen [™] Threadripper [™] Processors			
Memory	 - 8 x DIMM, max. 128GB, DDR4 3600+(O.C.)/3466(O.C.)/3333(O.C.)/3200(O.C.)/3 000(O.C.)/2800(O.C.)/2666/2400/2133 MHz, ECC and non-ECC, un-buffered memory 			
	- Quad channel memory architecture			
	* Please refer to Memory QVL (Qualified Vendors List) for details.			
	AMD Ryzen [™] Threadripper [™] Processors			
en antista d	- 4 x PCle 3.0 x16 slots (support x16/x8/x16/x8)			
slots	AMD X399 chipset			
	- 1 x PCle 2.0 x4 slot			
	- 1 x PCle 2.0 x1 slot			
Multi-GPU	Supports NVIDIA [®] 3-Way/2-Way/Quad-GPU SLI™ Technology			
support	Supports AMD 3-Way/2-Way/Quad-GPU CrossFireX™ Technology			
	AMD Ryzen [™] Threadripper [™] Processors*			
	 1 x M.2_1 Socket 3 with M key, type 2242/2260/2280 storage devices support (both SATA & PCIE 3.0 x 4 mode) 			
Storage	 1 x M.2_2 Socket 3 with vertical M Key, type 2242/2260/2280/22110 storage devices support (both SATA & PCIE 3.0 x 4 mode) 			
Storage	- 1 x U.2 port			
	AMD X399 chipset			
	- 6 x SATA 6Gb/s ports			
	 Supports PC e RA D configurations via onboard M.2 storages for up to 8 storage devices. 			
	Intel® Ethernet Controller I211-AT			
LAN	ASUS LAN Guard			
	ASUS Turbo LAN Utility			
	AMD Ryzen™ Threadripper™ Processors			
	- 8 x USB 3.1 Gen 1 ports (8 ports at back panel[blue])			
	AMD X399 chipset:			
USB	- 1 x USB 3.1 Gen 2 front panel connector			
	- 4 x USB 3.1 Gen 1 ports (4 ports at mid-board)			
	- 4 x USB 2.0 ports (4 ports at mid-board)			
	ASMedia [®] 3142 USB 3.1 Gen 2 controller			
	- 2 x USB 3,1 Gen 2 ports (1 x Type-A and 1 x USB Type-C [™] , at back panel)			

	Realtek [®] S1220A 8-channel high definition audio CODEC featuring Crystal Sound 3				
	 Power pre-regulator reduces power input noise to ensure consistent performance 				
	 Separate layer for left and right track, ensuring both sound deliver equal quality 				
	- Impedance sense for front and rear headphone outputs				
	 Audio shielding ensures precise analog/digital separation and greatly reduced multi-lateral interference 				
	 EMI protection cover to prevent electrical noise to affect the amplifier quality 				
Audio	 Internal audio Amplifier to enhance the highest quality sound for headphone and speakers 				
Addio	- Unique de-pop circuit to reduce start-up popping noise to audio outputs				
	 Premium Japan-made audio capacitors provides warm, natural, and immersive sound with exceptional clarity and fidelity 				
	- High quality 120dB SNR stereo playback output (Line-out@back) & 113dB SNR input (Line-in) support				
	 Supports up to 32-Bit/192kHz playback* 				
	- DTS [®] Headphone:X™				
	- DTS® Connect				
	- Supports jack-detection, multi-streaming, front panel jack-retasking (MIC)				
	- Optical S/PDIF out port at back I/O				
	* Due to limitations in HDA bandwidth, 32-Bit/192kHz is not supported for 8-Channel audio. 32-Bit/192kHz is only available under Windows [®] 10.				
	<performance></performance>				
	OC Design: ASUS PRO Clock Technology				
	 Full BCLK range for extreme overclocking performance. 				
	5-Way Optimization				
	 Whole system optimization with a single click! Perfectly consolidates better CPU performance, power saving, digital power control, system cooling and app usages. 				
	DIGI+ Power Control				
	- CPU Power: Digital 8+3 phase power design				
ASUS Exclusive	- DRAM Power: Digital 4-phase power design				
reatures	TPU				
	- Auto Tuning, TPU				
	EPU				
	Fan Xpert 4				
	Turbo App				
	UEFI BIOS				
	CrashFree BIOS 3				
	EZ Flash 3				
	EZ TUNING WIZARO				

	<gaming></gaming>
	2D Printing Friendly design
	E7 Managements
	<ez management=""></ez>
ASUS Exclusive	
Features	<ez diŷ=""></ez>
	Q-Design
	- ASUS Q-Code
	- ASUS Q-Connector
	- ASUS Q-DIMM
	- ASUS Q-LED (CPU, DRAM, VGA, Boot Device LED)
	- ASUS Q-Shield
	- ASUS Q-Slot
	ASUS SafeSlot
	- Protect your graphics card Investment
	ASUS 5X Protection III
	 ASUS SafeSlot Core - Fortified PCIe with solid soldering
	 ASUS LANGuard - Protects against LAN surges, lightning strikes and static-electricity discharges!
ASUS Special Features	 ASUS Overvoltage Protection - World-class circuit-protecting power design
	- ASUS DIGI+ VRM - Digital power design
	 ASUS DRAM Overcurrent Protection: Enhanced DRAM overcurrent protection
	 ASUS Stainless-Steel Back I/O: 3X corrosion-resistance for greater durability!
	- Al Suite 3
	- Ai Charger
ASUS Quiet	Quiet Thermal Design:
Thermal	- ASUS Fan Xpert 4
Solution	- ASUS Stylish MOS & M.2 heatsink Design
	1 x BIOS Flashback button
	1 x Optical S/PDIF out
Back Banal 1/0	1 x Intel LAN (RJ45) port
Ports	2 x USB 3,1 Gen 2 ports (Type-A + USB Type-C™ [teal blue])
	8 x USB 3.1 Gen 1 ports (blue)
	5 x Audio jacks (Line in, Front Speaker Out, Mic in, Center/Subwoofer, Rear Speaker Out)

	1 x USB 3.1 Gen 2 front panel connector
	2 x USB 3.0 Gen 1 connectors support additional 4 USB ports (19-pin)
	2 x USB 2.0 connectors support additional 4 USB ports
	1 x M.2_1 Socket 3 with M key, type 2242/2260/2280 storage devices support (both SATA & PCIE 3.0 x 4 mode)
	1 x M.2_2 Socket 3 with vertical M Key, type 2242/2260/2280/22110 storage devices support (both SATA & PCIE 3.0 x 4 mode)
	1 x U.2 port
	6 x SATA 6.0Gb/s connectors
	1 x 4-pin W_PUMP+ connector
	1 x 4-pin AIO_PUMP fan connector
	1 x 4-pin CPU fan connector
	1 x 4-pin CPU optional fan (CPU_OPT) connector
Internal I/O	1 x 3-pin Cover fan (COV_FAN) connector
connectors	3 x 4-pin Chassis fan connectors
	1 x 4-pin M.2 fan connector
	1 x 5-pin Extension Fan (EXT_FAN) connector
	1 x 2-pin Thermal sensor header
	1 x 24-pin EATX Power connector
	1 x 8-pin EATX 12V Power connector
	1 x 4-pin EATX 12V Power connector
	2 x RGB headers
	1 x Front panel audio connector (AAFP)
	1 x System panel connector (Q-Connector)
	1 x Q_Code LED
	1 x Clear CMOS header
	1 x Power-on button
BIOS Features	128 Mb Flash ROM, UEFI AMI BIOS, PnP, WfM2.0, SM BIOS 3.0, ACPI 6.1, Multi-language BIOS, ASUS EZ Flash 3, CrashFree BIOS 3, F11 EZ Tuning Wizard, F6 Qfan Control, F3 My Favorites, Last Modified log, F12 PrintScreen, and ASUS DRAM SPD (Serial Presence Detect) memory information
Manageability	WfM 2.0, DMI 3.0, WOL by PME, PXE
	Drivers
Support DVD contents	ASUS Utilities
	EZ Update
	Anti-virus software (OEM version)
Operating system support	Windows [®] 10 64-bit

Motherboard Layout



	Connectors / Jumpers / Buttons / Switches / Slots
1	DDR4 DIMM slots
2	TR4 CPU socket
3	RGB header (4-pin RGB_HEADER1-2)
4	ATX power connectors (24-pin EATXPWR; 8-pin EATX12V_1; 4-pin EATX12V_2)
5	CPU, CPU optional, AIO pump, water pump+, extension, M.2, and chassis fan connectors (4-pin CPU_FAN, 4-pin CPU_OPT, 3-pin COV_FAN; 4-pin AIO_PUMP, 4-pin

	W_PUMP+, 4-pin M.2_FAN, 5-pin EXT_FAN, 4-pin CHA_FAN1-3)
6	M.2 Sockets (M.2_1(Socket 3); M.2_2 (Socket 3))
7	USB 3.1 Gen 2 front panel connector (U31G2_C1)
8	USB 3.1 Gen 1 connectors (20-1 pin U31G1_910, U31G1_1112)
9	3D Mount holes
10	U.2 connector (U.2)
11	AMD Serial ATA 6 Gb/s connectors (7-pin SATA6G_1-6)
12	System panel connector (20-5 pin PANEL)
13	Clear RTC RAM jumper (2-pin CLRTC)
14	Thermal Sensor connector (2-pin T_SENSOR)
15	USB 2.0 connectors (10-1 pin USB12; USB34)
16	Power-on button
17	Q-Code LED
18	Front panel audio connector (10-1 pin AAFP)

Asus Motherboard Components



Motherboard Installation

Before removing the Motherboard, ensure the power is off by checking this indicator light. (See section <u>Before you proceed</u>)

When lit, the onboard LED indicates that the system is ON, in sleep mode or in soft-off mode, not powered OFF.

Installing the ASUS Q-Shield

Place the I/O shield inside the chassis and press it into place so that it fits tightly and securely. Use caution so you do not deform the I/O shield.



Installing the Desktop Board

When installing the motherboard, make sure that you place it into the chassis in the correct orientation. Align the rear panel I/O ports with the rear panel I/O shield of the chassis.



• Place screws into the holes indicated by circles to secure the motherboard to the chassis. DO NOT overtighten the screws! Doing so can damage the motherboard.



Jumpers

Setting the BIOS Configuration Jumper

Ľ

• Always turn off the power to the computer before moving the jumper. Moving the jumper with the power on may result in unreliable computer operation.

The diagram below shows the location of the Clear RTC *RAM* jumper.



Clear RTC RAM jumper (2-pin CLRTC)

This jumper allows you to clear the Real Time Clock (RTC) RAM in CMOS. You can clear the CMOS memory of date, time and setup parameters by erasing the CMOS RTC RAM data. The onboard button cell battery powers the RAM data in CMOS, which includes system setup information such as system passwords.

- 1. Observe the precautions in "Before You Proceed".
- 2. Turn off all *peripheral* devices connected to the computer. Turn off the computer. Disconnect the computer's power cord from the AC power source (wall outlet or power adapter).
- 3. Remove the computer cover.
- 4. Short-circuit pin 1-2 with a metal object or jumper cap for about 5-10 seconds.
- 5. Move the jumper cap from pins 1 -2 (default) to pins 2-3 for about 5 to 10 seconds, then move the cap back to pins 1-2.
- Replace the cover, plug in the computer, turn on the computer, and allow it to boot. During the boot process, hold down the <Delete> key to enter the BIOS setup and to re-enter data.



• Except when clearing the RTC RAM, never remove the cap from the CLRTC jumper default position. Removing the cap will cause system boot failure!



- You do not need to clear the RTC when the system hangs due to overclocking. For system failure due to overclocking, use the C.P.R. (CPU Parameter Recall) feature. Shut down and reboot the system so the BIOS can automatically reset parameter settings to default values.
- Due to the chipset behavior, AC power off is required to enable C.P.R. function. You must turn off and on the power supply or unplug and plug the power cord before rebooting the system.

Rear Panel Connectors



Rear Panel Connectors				
1. USB BIOS Flashback Button	6. USB 3.1 Gen 1 ports 3,4			
2. USB 3.1 Gen 1 ports 5,6,7 and 8	7. USB 3.1 Gen 2 Type-C port EC1			
3. Intel LAN port (LAN1)	8. Optical S/PDIF Out port			
4. USB 3.1 Gen 1 ports 1,2 (bottom port supports USB BIOS Flashback)	9. Audio jacks			
5. USB 3.1 Gen 2 Type-A port EA2				

USB 3.1 Gen1 / Gen 2 devices can only be used for data storage. USB 3.0 ports are backward compatible with USB 2.0 and USB 1.1 devices. The USB 3.0 ports are SuperSpeed, high-speed, full-speed, and low-speed capable. USB 3.0 support requires both an operating system and drivers that fully support USB 3.0 transfer rates.

It is strongly recommended that you connect your devices to ports with matching data transfer rate. Please connect your USB 3.1 Gen 1 devices to USB 3.1 Gen 1 ports and your USB 3.1 Gen 2 devices to USB 3.1 Gen 2 ports for faster and better performance for your devices.

Audio Subsystem

The onboard audio subsystem consists of the following component s:

- AMD X399 Chipset
- RealTek S1220A CODEC

The subsystem has the following headers and connectors:

- Six back panel audio connectors (including one Optical S/PDIF out port)
- High Definition (HD) Audio front panel header that provides mic in and line out signals for front panel audio connectors

The audio subsystem supports the following features:

- Advanced jack detection for the back panel analog audio jacks that enables the audio codec to recognize the device that is connected to an audio port. The front panel audio jacks are capable of re-tasking according to the user's definition, or can be automatically switched depending on the recognized device type.
- Independent multi-streaming.

LAN Subsystem

The board's Gigabit (10/100/1000 Mb/s) LAN subsystem includes:

- AMD X399 Chipset
- Intel I211-AT Gigabit Ethernet LAN Controller
- An RJ-45 LAN connector with integrated status LEDs

The subsystem features:

- CSMA/CD protocol engine
- LAN connect *interface* between the Intel PCH and the LAN controllers
- PCI bus power management
- ACPI technology support
- LAN wake capabilities

Two LEDs are built into the RJ-45 LAN connector located on the back panel. These LEDs indicate the status of the LAN.

This table describes the LED states when the board is powered up and the LAN subsystem is operating.

Activity Link LED		Speed I	.ED	
Status	Description	Status	Description	
Off	No link	Off	10 Mbps connection	
Orange	Linked	Orange	100 Mbps connection	ACT/LINK SPEED LED LED
Orange (Blinking)	Data activity	Green	1 Gbps connection	
Orange (Blinking then steady)	Ready to wake up from S5 mode			LAN port

Internal Connectors

Before connecting cables to any of the internal headers or connectors, observe the precautions in "Before You Proceed".

Front Panel Audio Header (10-1 pin AAFP)

This connector is for a chassis-mounted front panel audio I/O module that supports either HD Audio or legacy AC`97audio standard. Connect one end of the front panel audio I/O module cable to this connector.



PRIME X399-A Front panel audio connector

USB 3.1 Gen 2 front panel connector (U31G2_C1)

This connector allows you to connect a USB 3.1 Gen 2 module for additional USB 3.1 Gen 2 ports. The latest USB 3.1 Gen 2 connectivity provides data transfer speeds of up to 10 Gbps.



PRIME X399-A USB 3.1 Gen 2 front panel connector

USB 3.1 Gen 1 front connectors (20-1 pin U31G1_910; U31G1_112)

These connectors allow you to connect a USB 3.1 Gen 1 module for additional USB 3.1 Gen 1 front or rear panel ports. With an installed USB 3.1 Gen 1 module, you can enjoy all the benefits of USB 3.1 Gen 1 including faster data transfer speeds of up to 5 Gb/s, faster charging time for USB-chargeable devices, optimized power efficiency, and backward compatibility with USB 2.0.



USB 2.0 connector (10-1 pin USB12; USB34)

This connector is for USB 2.0 ports. Connect the USB module cable to this connector, then install the module to a slot opening at the back of the system chassis. This USB connector complies with USB 2.0 specification that supports up to 480 Mb/s connection speed.



PRIME X399-A USB 2.0 connectors

CPU, CPU optional, AIO pump, water pump+, extension, M.2 and chassis fan connectors (4-pin CPU_FAN; 4-pin CPU_OPT; 4-pin AIO_PUMP; 4-pin W_PUMP+; 4-pin M.2_FAN; 5-pin EXT_FAN, 4-pin CHA_FAN1-2)

Connect the fan cables to the fan connectors on the motherboard, ensuring that the black wire of each cable matches the ground pin of the connector.

- DO NOT forget to connect the fan cables to the fan connectors. Insufficient air flow inside the system may damage the motherboard components. These are not jumpers! Do not place jumper caps on the fan connectors!
 - Ensure that the CPU fan cable is securely installed to the CPU fan connector.



- The CPU_FAN connector supports the CPU fan of maximum 1A (12 W) fan power.
- W_PUMP+ function support depends on a water cooling device.
- Connect the fan of your water cooling kit to the AIO_PUMP connector.

res

AMD Serial ATA 6.0 Gb/s connectors (7-pin SATA6G_1-6)

These connectors connect to Serial ATA 6.0 Gb/s hard disk drives using Serial ATA 6.0 Gb/s signal cables. You can create a *RAID* 0, 1, or 10 configuration with the RaidXpert2 Configuration Utility through the onboard AMD X399 chipset.



PRIME X399-A Serial ATA 6.0Gb/s connectors



rel

• These connectors are set to **[AHCI Mode]** by default. If you intend to create a Serial ATA RAID set using these connectors, set the SATA Mode item in the BIOS to **[RAID]**.

ATX power connectors (24-pin EATXPWR; 8-pin EATX12V_1; 4-pin EATX12V_2)

These connectors are for ATX power supply plugs. The power plugs are designed to fit these connectors in only one orientation. Find the proper orientation and push down firmly until the connectors completely fit.



- 1. Observe the precautions in "Before You Proceed".
- 2. Connect the 12 V processor core voltage power supply cable to the 8-pin connector (A).
- 3. Connect the main power supply cable to the 2×12 pin connector (C).



M.2 sockets (M.2_1(Socket 3); M.2_2(Socket 3))

These sockets allow you to install M.2 SSD modules (purchased separately).


System panel connector (20-5 pin PANEL)

This connector supports several chassis-mounted functions.



PRIME X399-A System panel connector

• System power LED (2-pin or 3-1 PWR_LED)

This 2-pin or 3-pin connector is for the system power LED. Connect the chassis power LED cable to this connector. The system power LED lights up when you turn on the system power, and blinks when the system is in sleep mode.

- Hard disk drive activity LED (2-pin HDD_LED) This 2-pin connector is for the HDD Activity LED. Connect the HDD Activity LED cable to this connector. The HDD LED lights up or flashes when data is read from or written to the HDD.
- System warning speaker (4-pin SPEAKER) This 4-pin connector is for the chassis-mounted system warning speaker. The speaker allows you to hear system beeps and warnings.

• ATX power button/soft-off button (2-pin PWRSW)

This connector is for the system power button. Pressing the power button turns the system on or puts the system in sleep or soft-off mode depending on the operating system settings. Pressing the power switch for more than four seconds while the system is ON turns the system OFF.

• Reset button (2-pin RESET)

This 2-pin connector is for the chassis-mounted reset button for system reboot without turning off the system power.

Thermal sensor connector (2-pin T_SENSOR)

This connector is for the thermistor cable that allows you to monitor the temperature of your motherboard's critical components and connected devices. Connect the thermistor cable and place the sensor on the device or the motherboard's component to detect its temperature.



• The thermistor cable must be purchased separately.

U.2 connector (U.2)

This motherboard comes with a U.2 connector which supports PCIe 3.0 x4 NVM Express storage devices.



PRIME X399-A U.2 connector

AURA RGB headers (4-pin RGB_HEADER1-2)

These connectors are for RGB LED strips.



Thime X000-A hab headers

- These RGB headers support 5050 RGB multi-colour LED strips (12V/G/R/B, with a maximum power rating of 2A (12V), and no longer than 2 metres.
 - Before you install or remove any component, ensure that the ATX power supply is switched off or the power cord is detached from the power supply. Failure to do so may cause severe damage to the motherboard, peripherals or components.



- Actual lighting and colour will vary with LED strip.
- If your LED strip does not light up, check if the RGB LED extension cable and the RGB LED strip is connected in the correct orientation, and the 12V connector is aligned with the 12V header on the motherboard.
- The LED strip will only light up under the operating system.
- The LED strip is purchased separately.

Installing & Removing a PCI Card

PCI and PCI Express * Auto Configuration

If you install a PCI Express add-in card in your computer, the PCI Express auto-configuration utility in the BIOS automatically detects and configures the resources (IRQs, DMA channels, and I/O space) for that add-in card. You do not need to run the BIOS Setup program after you install a PCI Express add-in card.



• When installing a PCI Express card on the Desktop Board, ensure that the card is fully seated in the PCI Express connector before you power on the system. If the card is not fully seated in the connector, an electrical short may result across the connector pins. Depending on the over-current protection of the power supply, certain Desktop Board components and/or traces may be damaged.



Installing PCI Express x16 Graphics Cards

If you are installing a single *PCI Express* x16 graphics card, install it in the *PCI Express* primary connector for optimum performance. Follow these instructions to install a PCI Express x16 card:

- 1. Observe the precautions in "<u>Before</u> You Proceed".
- 2. Place the card in a *PCI Express* x16 connector and press down on the card until it is completely seated in the connector and the card retention notch on the card snaps into place around the retention mechanism pin on the connector.
- 3. Secure the card's metal bracket to the chassis back panel with the retention mechanism



Installing Linked PCI Express x16 Graphics Cards

The Desktop Board supports the use of linked *PCI Express* x16 graphics cards with Nvidia SLI technology and AMD CrossFire X technology.

When installing linked graphics cards in the *PCI Express* x16 connectors, refer to the card manufacturer's instructions to determine correct card placement and interconnection.



• The installations steps that follow provide general instructions.

To install two or three linked *PCI Express* graphics cards:

- 1. Observe the precautions in "<u>Before You</u> <u>Proceed</u>".
- Install the first card in the PCI Express x16 connector as described in "Installing PCI Express x16 Graphics Cards"
- 3. Place the second card in the secondary *PCI Express* x16 connector (A) and press down on the card until it is completely seated in the connector and the card retention notch on the card snaps into place around the retention mechanism pin on the connector. Do the same for the third card.
- 4. Secure the card's metal bracket to the



chassis back panel with a screw (B) or the retention mechanism.

- 5. Connect the two or three cards together with the SLI or CrossFire bridge (C) as shown.
- 6. Connect the *monitor* cable to the graphics cards according to the manufacturer's instructions.

Installing PCI Express x1 Cards

While there are some graphics cards that are PCI Express x1, most cards that fit in this slot are Network adapter cards or SATA, USB, Serial or Parallel controller cards. If you are installing a single *PCI Express* x1 card, install it in the *PCI Express* primary connector for optimum performance. Follow these instructions to install a PCI Express x1 card:

- 1. Observe the precautions in "Before You Proceed".
- 2. Place the card in a *PCI Express* x1 connector and press down on the card until it is completely seated in the connector and the card retention notch on the card snaps into place around the retention mechanism pin on the connector.
- 3. Secure the card's metal bracket to the chassis back panel with the retention mechanism



Onboard Switches and Buttons

The board contains the following buttons and switches that can be used to control board operation in order to fine-tune performance when working on a bare or open-case system. This is ideal for overclockers and gamers who continually change settings to enhance system performance:

- BIOS Flashback button
- Power-on button

USB BIOS Flashback Button

USB BIOS Flashback allows you to easily update the BIOS without entering the BIOS or operating system. Just connect the USB storage device containing the BIOS file into the USB port, press USB BIOS Flashback button for three seconds, and the BIOS is updated automatically.



BIOS Flashback button

USB BIOS Flashback port

To use USB BIOS Flashback:

- 1. Insert the USB storage device into the USB BIOS Flashback port.
 - \bullet We recommend the use of a USB 2.0 storage device to save the latest BIOS version for better compatibility and stability.
- 2. Rename the file as X299A.CAP, then copy it to your USB storage device.
- 3. Shut down your computer.
- 4. Press the BIOS Flashback button for three seconds until the Flashback LED blinks three times, indicating that the BIOS Flashback function is enabled.
- 5. Wait until the light goes out, indicating that the BIOS updating process is completed.



- Do not unplug portable disk, power system, or press the CLR_CMOS button while BIOS update is ongoing, otherwise the update will be interrupted. In case of interruption, please follow the steps again.
 - If the light flashes for five seconds and turns into a solid light, this means that the BIOS Flashback is not operating properly. This may be caused by improper installation of the USB storage device and filename/file format error. If this scenario happens, please restart the system to turn off the light.
 - Updating the BIOS has risks. If the BIOS program is damaged during the process and results in the system's failure to boot up, please contact the Northern Micro Service Department.

Power-On Button

The motherboard comes with a power-on button that allows you to power up or wake up the system. The button also lights up when the system is plugged to a power source indicating that you should shut down the system and unplug the power cable before removing or installing any motherboard component.



Onboard LEDs

POST State LEDs

The POST State LEDs provide the status of these key components during POST (Power-On-Self Test): CPU, memory modules, VGA card, and hard disk drives. If an error is found, the critical component's LED stays lit up until the problem is solved.



Q-Code LEDs

The Q-Code LED design provides you with a 2-digit error code that displays the system status. Refer to the Q-Code table on the next page for details.



Q-Code table

Code	Description	
00	Not used	
01	Power on. Reset type detection (soft/hard).	
02	AP initialization before microcode loading	
03	System Agent initialization before microcode loading	
04	PCH initialization before microcode loading	
06	Microcode loading	
07	AP initialization after microcode loading	
08	System Agent initialization after microcode loading	
09	PCH initialization after microcode loading	
0B	Cache initialization	
0C – 0D	Reserved for future AMI SEC error codes	
0E	Microcode not found	
OF -	Microcode not loaded	
10	PEI Core is started	
11 – 14	Pre-memory CPU initialization is started	
15 – 18	Pre-memory System Agent initialization is started	
19 – 1C	Pre-memory PCH initialization is started	
2B – 2F	Memory initialization	
30	Reserved for ASL (see ASL Status Codes section below)	
31	Memory Installed	
32 - 36	CPU post-memory initialization	
37 – 3A	Post-Memory System Agent initialization is started	
3B – 3E	Post-Memory PCH initialization is started	
4F	DXE IPL is started	
50 – 53	Memory initialization error. Invalid memory type or incompatible memory speed	
54	Unspecified memory initialization error	
55	Memory not installed	
56	Invalid CPU type or Speed	
57	CPU mismatch	
58	CPU self test failed or possible CPU cache error	
59	CPU micro-code is not found or micro-code update is failed	

Code	Description
5A	Internal CPU error
5B	Reset PPI is not available
5C – 5F	Reserved for future AMI error codes
E0	S3 Resume is stared (S3 Resume PPI is called by the DXE IPL)
E1	S3 Boot Script execution
E2	Video repost
E3	OS S3 wake vector call
E4 – E7	Reserved for future AMI progress codes
E8	S3 Resume Failed
E9	S3 Resume PPI not Found
EA	S3 Resume Boot Script Error
EB	S3 OS Wake Error
EC – EF	Reserved for future AMI error codes
F0	Recovery condition triggered by firmware (Auto recovery)
F1	Recovery condition triggered by user (Forced recovery)
F2	Recovery process started
F3	Recovery firmware image is found
F4	Recovery firmware image is loaded
F5 – F7	Reserved for future AMI progress codes
F8	Recovery PPI is not available
F9	Recovery capsule is not found
FA	Invalid recovery capsule
FB – FF	Reserved for future AMI error codes
60	DXE Core is started
61	NVRAM initialization
62	Installation of the PCH Runtime Services
63 - 67	CPU DXE initialization is started
68	PCI host bridge initialization
69	System Agent DXE initialization is started
6A	System Agent DXE SMM initialization is started
6B – 6F	System Agent DXE initialization (System Agent module specific)

Code	Description
70	PCH DXE initialization is started
71	PCH DXE SMM initialization is started
72	PCH devices initialization
73 – 77	PCH DXE Initialization (PCH module specific)
78	ACPI module initialization
79	CSM initialization
7A – 7F	Reserved for future AMI DXE codes
90	Boot Device Selection (BDS) phase is started
91	Driver connecting is started
92	PCI Bus initialization is started
93	PCI Bus Hot Plug Controller Initialization
94	PCI Bus Enumeration
95	PCI Bus Request Resources
96	PCI Bus Assign Resources
97	Console Output devices connect
98	Console input devices connect
99	Super IO Initialization
9A	USB initialization is started
9B	USB Reset
9C	USB Detect
9D	USB Enable
9E – 9F	Reserved for future AMI codes
A0	IDE initialization is started
A1	IDE Reset
A2	IDE Detect
A3	IDE Enable
A4	SCSI initialization is started
A5	SCSI Reset
A6	SCSI Detect
A7	SCSI Enable
A8	Setup Verifying Password

Code	Description
A9	Start of Setup
AA	Reserved for ASL (see ASL Status Codes section below)
AB	Setup Input Wait
AC	Reserved for ASL (see ASL Status Codes section below)
AD	Ready To Boot event
AE	Legacy Boot event
AF	Exit Boot Services event
B0	Runtime Set Virtual Address MAP Begin
B1	Runtime Set Virtual Address MAP End
B2	Legacy Option ROM Initialization
B3	System Reset
B4	USB hot plug
B6	Clean-up of NVRAM
B7	Configuration Reset (reset of NVRAM settings)
88 BF	Reserved for future AMI codes
D0	CPU initialization error
D1	System Agent initialization error
D2	PCH initialization error
D3	Some of the Architectural Protocols are not available
D4	PCI resource allocation error. Out of Resources
D5	No Space for Legacy Option ROM
D6	No Console Output Devices are found
D7	No Console Input Devices are found
D8	Invalid password
D9	Error loading Boot Option (LoadImage returned error)
DA	Boot Option is failed (StartImage returned error)
DB	Flash update is failed
DC	Reset protocol is not available
B5	PCI bus hot plug

CPU Overview / Specs





Processor Number	AMD Threadripper 1920x
Base Frequency (GHz)	3.50
Total <i>Cache</i>	38MB
Cores / Threads	12 / 24
Memory Speed Support (DDR4)	2666

Installing a CPU



Before installing or removing a processor, make sure the AC power has been removed by unplugging the power cord from the computer; the standby power LED should not be lit. Failure to do so could damage the processor and the board.

To install a processor, follow these instruction s:

- 1. Observe the precautions in "Before You Proceed".
- 2. Using a Torx screwdriver, remove the screws in sequence 3>2>1, then lift the load plate.



3. Use your fingers to pull up the tabs on both sides of the rail frame to release and lift to its fully open position .



4. Remove the external cap.



5. Slide the carrier frame with CPU into the rail frame until you hear a click sound, then remove the PnP cap.



6. Gently press down the rail frame until it latches to the socket housing, then press down the load plate.



 Slightly drive the three screws into the holes in sequence 1>2>3, just enough to attach the load plate to the socket. When the three screws are attached, tighten them in sequence 1>2>3 to completely secure the load plate. Then apply the Thermal Interface Material to the CPU.



Installing CPU Heatsink & Fan

The TR4 processor socket has four threaded holes for mounting a processor fan heat sink. The illustrations shows installation of a typical processor fan heat sink.

Apply thermal solution to the back of the processor prior to installing the fan. To install the fan, turn the four screw mounts clockwise (Figure 1 A and B below). To remove the fan, simply turn these mounts counterclockwise.



Connect the processor fan heat sink cable to the 4-pin processor fan header (Figure 2 below).



When using a liquid cooled solution, the Intel TS13X module is the best choice. here are the steps for installing the Intel liquid cooling solution.



1. Attach fan to heat dissipater with screws, using spacers between.

2. Attach fan/dissipater to chassis.





3. Situate mounting ring according to diagram.

4. Place special screw extenders into mounting ring.



5. Apply thermal paste to the center of the CPU mounting position on the motherboard.



6. Screw liquid reservoir onto mounting bracket and situate properly for motherboard.



7. Twist reservoir counterclockwise.



8. Screw reservoir/mounting ring assembly onto motherboard.



9. Attach cable connector from reservoir to fan assembly.



10. Attach hoses from reservoir.





11. Set switch to ON position if you want the fan to be lit up.

 Do not forget to connect the CPU fan connector! Hardware errors can occur if you fail to plug this connector.

System Memory Overview

The motherboard comes with eight DDR 4 (Double Data Rate 4) Quad Inline Memory Modules (DIMM) slots.

• A DDR4 module is notched differently from a DDR, DDR2, or DDR3 module. DO NOT install a DDR, DDR2, or DDR3 memory module into the DDR4 slot.



The Desktop Board supports the following memory and interface:

- Eight 288-pin Double Data Rate 4 (DDR4) Quad Inline Memory Module (DIMM) connectors with gold-plated contacts arranged in four channels
- 3600 (OC)/ 3466 (OC)/ 3333 (OC)/ 3200 (OC)/ 3000 (OC)/ 2800 (OC) /2666/2400/2133 MHz DDR4 ECC and non-ECC DIMM support
- Support for quad-channel memory interleaving
- Unbuffered, non-registered single or double-sided DIMMs with a voltage rating of 1.4V or less *memory*
- Minimum total system *memory* of 2 GB
- Up to 128 GB maximum total system memory

System Memory Configurations

You may install 8 GB, and 16 GB unbuffered and non-ECC DDR4 DIMMs into the DIMM sockets.

• You may install varying memory sizes in Channel A, Channel B, Channel C, and Channel D. The system maps the total size of the lower-sized channel for the dual channel configuration. Any excess memory from the higher-sized channel is then mapped for single-channel operation.

The Intel Core i7 processors support the following types of *memory* organization:



P

• The default memory operation frequency is dependent on its Serial Presence Detect (SPD), which is the standard way of accessing information from a memory module. Under the default state, some memory modules for overclocking may operate at a lower frequency than the vendor-marked value.

- For system stability, use a more efficient memory cooling system to support a full memory load (8 DIMMs) or overclocking condition.
- Always install the DIMMS with the same CAS Latency. For an optimum compatibility, we recommend that you install memory modules of the same version or data code (D/C) from the same vendor. Check with the vendor to get the correct memory modules.

Installing System Memory

Asus Desktop board Prime X399-A has eight 288-p in DDR4 DIMM sockets arranged in four channels (A, B, C, and D).

For optimal *memory* performance:

- Install DIMMs in numerical order (1-8).
- For dual-, and quad-channel operation install matched DIMMs of equal speed and size in each channel.
- If you are installing four or fewer DIMMs, use the lighter coloured sockets.



To install a DIMM, follow these steps:

- 1. Observe the precautions in "Before You Proceed".
- 2. Turn off all *peripheral* devices connected to the computer. Turn off the computer and disconnect the AC power cord.
- 3. Remove the computer's cover and locate the DIMM sockets.
- Make sure the clips at either end of the DIMM socket(s) are pushed outward to the open position.
- 5. Holding the DIMM by the edges, remove it from its anti-static package.
- 6. Position the DIMM above the socket. Align the small notch at the bottom edge of the DIMM with the keys in the socket.

- 7. Insert the bottom edge of the DIMM into the socket.
- 8. When the DIMM is inserted, push down on the top edge of the DIMM until the retaining clips snap into place. Make sure the clips are firmly in place.
- 9. Replace the computer's cover and reconnect the AC power cord.



Removing System Memory

To remove a DIMM, follow these steps:

- 1. Observe the precautions in "Before You Proceed".
- 2. Turn off all *peripheral* devices connected to the computer. Turn off the computer.
- 3. Remove the AC power cord from the computer.
- 4. Remove the <u>computer's cover</u>.
- 5. Gently spread the retaining clips at each end of the DIMM socket. The DIMM pops out of the socket.
- 6. Hold the DIMM by the edges, lift it away from the socket, and store it in an anti-static package.
- 7. Reinstall and reconnect any parts you removed or disconnected to reach the DIMM sockets.
- $8. \ \mbox{Replace the computer's cover and reconnect the AC power cord.}$

 Support the DIMM lightly with your fingers when pressing the retaining clips. The DIMM might get damaged if it flips out with extra force.



Hard Drive Overview



Physical Specifications

Capacity	512GB
Interface	PCIe SSD
Form Factor	M.2 2280

Physical Dimensions

Dimensions	22 ± 0.15 mm x 80 ± 0.15 mm x 2.38 mm
Weight	7.2 ± 0.5 g

Environmental Specifications

Operating Temperature	32 °F to 158 °F (0 °C to 70 °C)
Storage Temperature	-67 °F to 185 °F (-55 °C to 85 °C)
Vibration Operating	5.0 gRMS, 10-2000 Hz, 3 axes
Vibration non-operating	4.9 gRMS, 7–800 Hz, 3 axes
MTBF	1.75M hours
Total Bytes Written (TBW)	160

Performance (4KB QD32)

PCMark	180K
Sequential Read MB/s (Q=32, T=1)	2,050
Sequential Write MB/s (Q=32, T=1)	800
Random Read 4 KB IOPS (Q=32, T=4)	170 K
Random Write 4KB IOPS (Q=32, T=4)	134 K

Unpacking and Handling

Hard drives are precision instruments and should be handled with care during unpacking and installation; they can be damaged by rough handling, shock and vibration, or electrostatic discharge (ESD). Be aware of the following precautions when handling your hard drive .

- Do not unpack your hard drive until you are ready to install it.
- Your hard drive is packaged in a static shielding bag. Use this bag to place your hard drive on after unpacking.
- Save the packing materials in case you need to return your hard drive.
- Articles of clothing generate static electricity. Do not allow clothing to come in direct contact with the hard drive or circuit board components.
- Handle the hard drive by the sides only. Avoid touching the circuit board components.
- Do not drop or knock the hard drive.
- Do not stack hard drives or stand your hard drive on its edge.



• Your default drive may be a Solid State Drive (SSD). SSD drives have no moving parts and are more robust than traditional Hard Disk Drives. It is still good practice to be gentle with these electronic components. ESD precautions must be taken.

Hard Drive Removal

P

• Please see instruction on cover removal <u>Removing the Case Cover</u>

- Open the computer case and locate the hard drive. The hard drive is actually an M.2 Solid State Drive (SSD).
- Step 1 Insert the M.2 card firmly into the M.2 slot ensuring the pins and notches align correctly (parallel to the motherboard). Please note that the motherboard has two M.2 slots available for storage (B keyed card compatible) and one M.2 slot for WiFi, Bluetooth or cellular cards (E keyed card compatible). SSD's must be inserted in one of the two B keyed slots.
- Step 2 Using the screw that accompanies the replacement SSD, screw the non-keyed end of the M.2 card into the motherboard hole that aligns with the hole in the M.2 card.



Optical Drive Overview

Some configurations include a 51/4 inch DVD±RW drive.



Features

- 5 1/4" 16X, 130ms, 256kb
- Product Description: Internal DVD-Writer
- Colour: Black
- Interface : S-ATA
- Dimensions (LxWxH): 14.8 cm x 17.0 cm x 4.2 cm

Specifications

Write Speed	 <i>DVD</i>+R: <i>DVD</i>-R: <i>DVD</i>+RW: <i>DVD</i>-RW: <i>DVD</i>+R(DL): <i>DVD</i>-R (DL): <i>DVD</i>-RAM: CD-R: CD-RW: 	24X 24X 8X 6X 8X 8X 5X 48X 24X
Read Speed	 DVD+R: DVD-R: DVD+RW: DVD-RW: DVD-ROM: DVD+R(DL): DVD-R(DL): DVD-ROM(DL): CD-R: CD-RW: CD-ROM: 	16 X 16 X 12 X 12 X 12 X 16 X 12 X 12 X 12 X 12 X 48 X 40 X 48 X

Optical Drive Removal

L

• Please see instruction on cover removal <u>Removing the Case Cover</u>

- 1. Disconnect Optical power and data cables.
- 2. If there are any screws in the side of the optical drive, they will need to be removed with a Phillips screwdriver.
- 3. To remove the drive from the assembly, pull the yellow buttons towards yourself.





4. Slide the optical drive out of the assembly.

Software / Operating System

The Desktop Board provides full support for all versions of the following operating systems:

- Microsoft Windows 10 (64-bit and 32-bit editions)
- Microsoft Windows 8 (64-bit and 32-bit editions)
- Microsoft Windows 7 (64-bit and 32-bit editions)

ACPI

ACPI gives the operating system direct control over the power management and Plug and Play functions of a computer. The use of *ACPI* with the Desktop Board requires an operating system that provides full ACPI support.
Updating the BIOS

The new ASUS UEFI BIOS is a Unified Extensible Interface that complies with UEFI architecture, offering a user-friendly interface that goes beyond the traditional keyboard only BIOS controls to enable a more flexible and convenient mouse input. You can easily navigate the new UEFI BIOS with the same smoothness as your operating system. The term "BIOS" in this user manual refers to "UEFI BIOS" unless otherwise specified.

BIOS (Basic Input and Output System) stores system hardware settings such as storage device configuration, overclocking settings, advanced power management, and boot device configuration that are needed for system startup in the motherboard CMOS. In normal circumstances, the default BIOS settings apply to most conditions to ensure optimal performance. DO NOT change the default BIOS settings except in the following circumstances:

• An error message appears on the screen during the system bootup and requests you to run the BIOS Setup.

• You have installed a new system component that requires further BIOS settings or update.



• Inappropriate BIOS settings may result to instability or boot failure. We strongly recommend that you change the BIOS settings only with the help of a trained service personnel.



• When downloading or updating the BIOS file, rename it as **X399A.CAP** for this motherboard.

The *BIOS* Setup program can be used to view and change the *BIOS* settings for the computer. You can access the BIOS Setup program by pressing the **Delete** key after the **Power-On Self-Test** (POST) *memory* test begins and before the operating system *boot* begins.

There are two modes available to use the BIOS Setup program.

1. EZ Mode - by default the EZ mode screen appears when you enter the BIOS program.

splays the CPU/motherboard temperature, PU voltage output, CPU/chassis/power fan Selec seed, and SATA information	Displays the system p Click < or > to s ts the display language BIOS setup program	roperties of the selected mode witch EZ System Tuning modes Configures system overclocking
UEFI BIOS Utility - EZ Mode	"/	
Information CPU Temperature UME X399-A BIOS Ver. 0304 MD Ryzen Threadripper 1920 12-Core Processor wedd 3600 MHz	CPU Core Voltage 1.373 V Motherboard Temperatur	EZ System Tuning Click the icon to specify your preferred system settings for a power-saving system environment
emory: 8192 MB (DDR4 2133MHz) RAM Status SATA Informat	52°C 33°C	Perfermance Integy Saving
MM. A1: Samoung 8102MB 2122MHa CATACO 1: N/A MM. A2: N/A SATAGO 2: N/A MM. B1: N/A SATAGO 3: N/A MM_ B2: N/A SATAGO 4: N/A MM_ D2: N/A SATAGO 6: N/A MM_ C2: N/A SATAGO 6: N/A MM_ D1: N/A SATAGO 6: N/A MM_ D2: N/A MA2_2: N/A		Kormal Switch all System Use Flash Disk 1.00 (7639M8)
Isabled I Disabled CPU FAN CPU FAN CPU FAN OCPU FAN DCPU		UEFE: 35YSTEM USB Flash Disk 1.00 (7639M8)
Dext FAN1 Dext FAN2 1 0 NVA QFan Con	n 300 ^{<}	** Boot Menu(F8)
Displays the CPU Fan's speed. Click	Default(F5) Save & Exit(F10) Saves the changes and resets the syst	Advanced Mode(F7)
the button to manually tune the fans Loads optimized _ default settings	Click to go to Ad	dvanced mode Search on the FAQ Click to display boot devices —
	Selects	the boot device priority

 Advanced Mode - to access this mode, click Exit/Advanced Mode, then select Advanced Mode or press <F7> on your keyboard.
 Configuration fields

My Favorites Main <u>Ai Tweaker</u> Advance	d Monitor	Boot Tool E	xit	L달 Hardwa	are Monito
Target CPU Speed : 3200MHz Target DRAM Frequency : 2133MHz				CPU	Temperato
Overclocking Presets				4000 MHz	46°C
Ai Overclock Tuner	[Auto	•	BCLK 100.0 MHz	Core Voltag
Custom CPU Core Ratio		Auto	•	Ratio	
> CPU Core Ratio		Auto		40.0 x	
Performance Blas		Auto	I	Memory	
Memory Frequency		Auto	•	Frequency 2133 MHz	Vol_CHAS 1.199 V
Core Performance Boost		Auto	•	Capacity	Vol_CHCD
SMT Mode		Auto	•	8192 MB	1,199.4
Spread Spectrum		Auto Enabled		Voltage	
EPU Power Saving Mode		Disabled		+12V 11.837 V	+5V 5.068 V
Simultaneous multithreading. Default is Enabled.				*3.3V 3.313 V	
10112 10 11 3		Last Mo	dified EtMode	s(F7)]- <u>-</u>]	Search on F

This section tells you how to update the **BIOS** by using one of three different utilities:

- 1. **Asus Update:** Updates the *BIOS* in a Windows environment.
- 2. Asus EZ Flash 3: Updates the *BIOS* using a *USB* flash drive.
- 3. **ASUS CrashFree** *BIOS* **3**: Restores the *BIOS* using the motherboard support *DVD* or a *USB* flash drive when the *BIOS* file fails or gets corrupted.

EZ Update

EZ Update is a utility that allows you to update the motherboard BIOS in Windows environment.



Updating the BIOS using the ASUS EZ Flash 3 utility

ASUS EZ Flash 3 allows you to update the BIOS without having to use a bootable floppy disk or an OS-based utility.



• Before you start using this utility, download the latest BIOS from the ASUS website at <u>www.asus.com/support</u>.

To use this **BIOS** update method with USB:

- 1. Enter the Advanced Mode of the *BIOS* setup program. Go to the **Tool** menu to select **ASUS EZ Flash Utility** and then press <Enter> to enable it.
- 2. Insert the USB flash drive that contains the BIOS file.
- 3. Select "by USB"



- 4. Press <Tab> to switch to the **Drive** field.
 - 5. Press the Up/Down arrow keys to find the *USB* flash drive that contains the latest *BIOS*, and then press <Enter>.
 - 6. Press <Tab> to switch to the *Folder* Info field.
- 7. Press the Up/Down arrow keys to find the *BIOS* file, and then press <Enter> to perform the *BIOS* update process. Reboot the system when the update process is complete.

VELES UEFI BIOS Utility - Adv	anced Mode		11/2/11/1	1
ASUS EZ Flash 3 Utility v03.00				
🖹 Flash				
Model: PRIME X299-A	Version: 0101		Date: 04/12/2017	
File Path: fs2:\				
Drive	Folder			
③Internet (Offline)	06/24/2012 10:02	<dir></dir>	PerfLogs	
Storage Device(s) fs0:\ [3828 MB]	12/21/2015 16:37 06/03/2016 01:52	<dir> <dir></dir></dir>	\$Extend \$Recycle.Bin Decements and Settings	
fs1:\ fs2:\ [238121 M8]	06/03/2016 01:48	<dir></dir>	Intel	
	06/03/2016 01:55	<dir></dir>	Program Files (x86)	
	06/03/2016 01:55 06/14/2016 20:42	<dir> <dir></dir></dir>	ProgramData System Volume Information	
	12/21/2015 16:54	<dir></dir>	Users	



• This function can only support devices, such as a USB flash drive, with FAT32/16 and single partition.

• Do NOT shut down or reset the system while updating the BIOS to prevent system boot failure!

• To ensure system compatibility and stability, load the **BIOS** default settings by selecting **Load Optimized Defaults** on the **Exit** menu.

To use this **BIOS** update method with the Internet:

- 1. Enter the Advanced Mode of the *BIOS* setup program. Go to the **Tool** menu to select **ASUS EZ Flash Utility** and then press <Enter> to enable it.
- 2. Select "by Internet"

EZ Flash Update Please choose a way to update your BIOS.
by USB
Next

3. Press the Left/Right arrow keys to select an Internet connection method and then press <Enter>.

Network Connection Choose an internet connection method
DHCP PPPOE FixIP
Next Cancel

- 4. Follow the onscreen instructions to complete the update.
- 5. Reboot the system when the update process is done.



• To ensure system compatibility and stability, load the **BIOS** default settings by selecting **Load Optimized Defaults** on the **Exit** menu.

Restoring the BIOS with the ASUS CrashFree BIOS 3 Utility

The ASUS CrashFree *BIOS* 3 utility is an auto recovery tool that allows you to restore the *BIOS* file when it fails or gets corrupted during the updating process. You can restore a corrupted *BIOS* file using the motherboard support *DVD* or a *USB* flash drive that contains the *BIOS* file. The latest *BIOS* can be downloaded from www.asus.com/support_.

To recover the **BIOS**:

- 1. Turn on the system.
- 2. Insert the motherboard support *DVD* or the *USB* flash drive containing the *BIOS* file.
- 3. The utility automatically checks the devices for the *BIOS* file. When found, the utility reads the *BIOS* file and enters the ASUS EZ Flash 3 utility automatically.
- 4. The system requires that you enter the *BIOS* Setup to recover *BIOS* settings. To ensure system compatibility and stability, we recommend that you press <F5> to load the default *BIOS* values.



 Do NOT shut down or reset the system while updating the BIOS to prevent system boot failure!

Configuring for RAID

L

• The Motherboard includes the RaidXpert2 Configuration Utility that supports RAID 0, RAID 1 and RAID 10.

• If you want to install a Windows operating system to a hard disk drive included in a RAID set, you have to create a RAID driver disk and load the RAID driver during OS installation.

RAID Definitions

RAID 0 (Data striping)

RAID 0 optimizes two identical hard disk drives to read and write data in parallel, interleaved stacks. Two hard disk drives perform the same work as a single drive but at a sustained data transfer rate, double that of a single disk alone, thus improving data access and *storage*. Use of two new identical drives is required for this setup.

RAID 1 (Data mirroring)

RAID 1 copies and maintains an identical image of data from one drive to a second drive. If one drive fails, the disk array management *software* directs all applications to the surviving drive as it contains a complete copy of the data on the other drive. This *RAID* configuration provides data protection and increases fault tolerance to the entire system. Use two new drives or use an existing drive and a new drive for this setup. The new drive must be of the same size or larger than the existing drive.

RAID 10

RAID 10 is data striping and data mirroring combined without parity having to be calculated and written. With the *RAID* 10 configuration you get all the benefits of both *RAID* 0 and *RAID* 1 configurations. Use four new hard disk drives or use an existing drive and three new drives for this setup.

The motherboard supports Serial ATA hard disk drives and NVMe SSD storage devices. For optimal performance, install identical drives of the same model and capacity when creating a disk array.

RaidXpert2 Configuration Utility in UEFI BIOS

To enter the RaidXpert2 Configuration Utility in UEFI BIOS:

- 1. Enter the BIOS Setup during POST.
- 2. Go to the Advanced menu, select SATA Configuration , then set SATA Mode to $[\mbox{RAID}\,].$

- 3. Configure additional settings for your storage device and RAID configuration:
 - If you are using Hyper M.2 x16 cards (purchased separately), go to the Advanced menu, select **Onboard Devices Configuration**, then set all the corresponding PCIe slots to [**PCIe RAID Mode**].
 - If you are setting up an NVMe RAID set, go to the Advanced menu, select **AMD PBS**, then set **NVMe RAID mode** to [**Enabled**].
- 4. Go to the Boot menu, select **CSM (Compatibility Support Module)**, select **Launch CSM**, then set the item to [**Disabled**].
- 5. Save your changes and exit the BIOS Setup, then enter the BIOS Setup again.
- 6. Go to the Advanced menu, select **RaidXpert2 Configuration Utility**, to display the RaidXpert2 Configuration Utility menu.



Due to chipset limitations, when SATA ports are set to RAID mode, all SATA ports run at RAID mode together.



Creating a RAID Set

1. From the RaidXpert2 Configuration Utility menu, go to **Array Management**, then select **Create Array** to enter the Create Array menu. The following screen appears.

My Favorites Main Ai T	weaker <u>Advanced</u>	Monitor Boot Tool Exit	Hardware Monit
Advanced\RAIDXpert2 Configuration	Utility\Create Array		CPU
Select RAID Level:		RAID 0	Frequency Temperati
Select Physical Disks			APU Freq Core Volta
Configure Array Parameters:			100.0 MHz 1.264 V
			Ratio
Read Cache Policy:		Read Ahead	Memory
Write Cache Policy:		Write Back	Frequency Voltage 2133 MHz 1.200 V
Create Array			Capacity

- 2. When the **RAID Level** item is selected, press <Enter> to select the RAID level to create, and then press <Enter>.
- 3. Under Select Physical Disks, press <Enter>. The following screen appears.

You can select SATA, SSD or both. Turn ${\bf ON}$ the disks you want to include in the RAID set and select ${\bf Apply}\ {\bf Changes}$, then press <Enter>.

	an Control(F6)	7 Hot Keys	En A		11/2	
My Favorites Main Ai Tweaker Advanced	Monitor	Boot 1	Tool Exit		Hardwa	are Monitor
Select Media Type:		SSD		-	CPU	
		SATA			Frequency 3000 MHz	Temperature 43°C
Minimum required number of disks: Maximum allowed number of disks:					APU Freq 100.0 MHz	Core Voltage 1.264 V
Physical Disk 0:1:0, SATA, 119.9 GB, Ready		On	Off		Ratio	
Physical Disk 0:1:1, SATA, 255.9 GB, Ready		On	Off		30×	
Physical Disk 0:1:3, SATA, 525.0 GB, Ready		On	Off		Memory	
Physical Disk 0:1:5, SATA, 255.9 GB, Ready		On	Off		Frequency	Voltage
Check All					Capacity 8192 MB	1.200 V
Uncheck All					Voltage	
≻ Apply Changes					12.033 V	4.986 V

4. When returning to the RaidXpert2 Configuration Utility menu, select the Array Size and other detailed policies, press <Enter>. Save the changes when finished.



You can specify the array size to be created. Choosing the value 0 will set the maximum supported array size when a valid configuration is selected.

VEFI BIOS Utility - Advanced Mode 01/03/2017 04:59 [☆] ⊕English	
My Favorites Main Ai Tweaker Advanced Monitor Boot Tool Exit Advanced\RAIDXpert2 Configuration Utility\Create Array Select RAID Level: Select Physical Disks Configure Array Parameters:	Hardware Monitor CPU Frequency Temperature 3000 MHz 43°C APU Freq Core Voltage 100.0 MHz 1.264 V
Array Size: 478 Array Size Unit: GB (GigaBytes) Read Cache Policy: Read Ahead Write Cache Policy: Write Back > Create Array	Kalloo 30x Memory Frequency Voltage 2133 MHz 1.200 V Capacity 8192 MB
Allows the user to specify the size of the Array to be created. A value of 0 will be reset to the maximum supported Array size when a valid configuration has been selected.	Voltage +12V +5V 12.033 V 4.986 V +3.3V 3.335 V

Deleting a RAID Set



Be cautious when deleting a RAID set. You will lose all data on the hard disk drives when you delete a RAID set.

To delete a RAID set:

 Select RaidXpert2 Configuration Utility, then select Delete Array and press <Enter>. Select the Array you want to delete and select Delete Array, press <Enter>.

DEFI BIOS Utility - Advanced Mode 01/03/2017 05・02 ♥ ⊕ English ₪ MyFavorite(F3) ≫Qfan Control(F6) ⑦ Hot Keys	
My Favorites Main Ai Tweaker <u>Advanced</u> Monitor Boot Tool Exit	Hardware Monitor
Advanced\RAIDXpert2 Configuration Utility\Delete Array	СРО
Select Array 1, RAID0, 477.7 GB, Norm 👻	Frequency Temperature 3000 MHz 43°C
> Delete Array	APU Freq Core Voltage
	100.0 MHz 1.275 V
	Ratio
	30x
	Memory
	Frequency Voltage
	2133 MHz 1.200 V
	Canacity
	8192 MB
	Voltage
	12.033 V 4.986 V

2. Select **On** to confirm your choice and then select **Yes** to delete the RAID Array and return to the **RaidXpert2 Configuration Utility** menu, or select **No** to cancel.

UEFI BIOS Utility - Advanced Mode 01/03/2017 05:02 [¢] ⊕ English	
My Favorites Main Ai Tweaker <u>Advanced</u> Monitor Boot Tool Exit	Hardware Monitor
← Advanced\RAIDXpert2 Configuration Utility\Delete Array\Warning Deleting an Array will delete all of the data available on it. Are you sure you want to delete the selected Array(s)?	CPU Frequency Temperature 3000 MHz 44*C
Confirm On Off	APU Freq Core Voltage 100.0 MHz 1.264 V
 YES Deleting an Array may take up to 15 seconds. After selecting Yes, please wait for the operation to complete. NO 	Ratio 30x Memory Frequency Voltage
	2133 MHz 1.200 V Capacity 8192 MB Voltage

Creating a RAID driver disk in Windows

- 1. During the OS installation, click **Load Driver** to allow you to select the installation media containing the RAID driver. Make sure the UEFI driver for the optical drive is loaded.
- 2. Insert the supported USB flash drive with the RAID driver into the USB port, and then click ${\bf Browse}$.
- 3. Click the name of the device you've inserted, go to **Drivers**, then **RAID**, and then select the RAID Bottom drivers first and click **OK**, then select the RAID driver for the corresponding OS version, click **OK**.
- 4. Follow the succeeding screen instructions to complete the installation.

How to Place a Service Call

Northern Micro provides support for your Spirit system from coast to coast. This section features our main service calls procedures.

Via telephone

Customers can contact our National Call Centre at 1-800-563-1007 (extension 241).

Our regular business hours are Monday to Friday from 7:30AM-5:00PM.

Via the Internet

You are also invited to use our self-serve services on the Web. To place your service call, please go to <u>www.northernmicro.com</u>.

Via our Portal

Service calls can also be placed via our portal. Access to the portal can be requested by contacting <u>PortalRequest@nmicro.ca</u>.

General procedures:

To speed-up the process, our bilingual call coordinators will ask you for:

- product type and serial number;
- problem description;
- address, phone numbers, etc.

Once your work order is registered, a technician will contact you within the next hour during regular business hours.

Your dedicated technician will make a diagnostic and will offer suggestions. He or she will also determine if the problem is *software* or *hardware* related. If the problem is related to *hardware*, a technician will be deployed on site to solve the problem. If the problem is related to *software* and a technician is deployed on site, some charges may apply. Please note that most problems are solved over the phone. In either case, the technician will communicate with the client to confirm the time of the visit.

Replacing CMOS Battery

When you turn your computer off, the CMOS chip stores information about date and time and configuration details necessary to start and run the system. A small button cell (coin) battery provides the power for the CMOS chip memory.

Replacement batteries are available from Northern Micro's service department. After you replace the battery, you must reset the date and time and restore the configuration settings. To do so, run the setup utility.

See BIOS Setup Program to find out how to run the setup utility.

Generally CMOS batteries last for about five years. Here are some signs that your CMOS battery needs to be replaced.

- 1. Invalid configuration will appear on your screen.
- 2. Run Setup appears on your screen.
- 3. Press F1 to continue appears on your screen.
- 4. Invalid drive specification appears on the screen after you've pressed F1.
- 5. Clock Error or Clock Message appears on your screen.
- 6. The clock on the computer loses time.
- 7. The computer is constantly showing the wrong date

To replace the CMOS battery, push the adjacent retention clip and the battery will pop out of the socket.



Install the replacement battery (CR2032 button cell) by pushing it into the socket until it snaps into place.

Troubleshooting

- 1. No display when power on
- 2. Can't enter OS
- 3. Power supply does not work well
- 4. The PC works very slowly
- 5. <u>CPU fan is too noisy</u>
- 6. Freeze frequently
- 7. Can't connect to the Internet
- 8. 4GB of Memory Installed, Computer only Recognizes 3.0GB or less
- 9. Audio is abnormal
- 10. How_to_have_dual_video_output_
- 11. BIOS_Errors

No display when power on

Solution

Make sure all cables are connected well and the power is on:

- Clear the CMOS
- Keep the necessary components (a CPU, a *memory* module, and a graphic card) on board to test:
- If the PC does *POST* well with the minimum system components:
 - Please plug in the other components one by one to find out which one may cause this problem.
 - If the PC still cannot POST at all:
 - The power LED on the motherboard is on and the CPU fan works well, please connect the speaker connector to check if there are any beeps
 - Memory issue: Beep (1 long 2 short)
 - Clean the golden contacts of the *memory* module
 - Clean the *memory* slots
 - Leave only one *memory* module to test
 - If convenient, please change different *memory* modules to test again
 - Graphics card issue: Beep (1 long 3 short)
 - · Clean the golden contacts of the graphics card

- Clean the graphics card slots
- Try to test the onboard graphics card if there is onboard video integrated
- If convenient, please change to a different graphic card to test again
- CPU (processor) issue: Beep (5 short)
 - Check whether the CPU is in the motherboard manufacturer's CPU support list
 - Check whether there is any damage to your CPU or CPU socket.
 - Check whether the CPU fan is correctly connected
 - Check whether the ATX_12V power cable is connected well
 - If possible try to test with another CPU
- The power LED on the motherboard is off and the CPU fan does not work well
 - Check the power pin
 - Check the power supply, try exchanging the power supply for another good one

Cannot enter OS

Solution

- During POST
 - Un-plug any newly added devices to see if the issue disappears.
 - Keep the necessary components (a CPU, a *memory* module, and a graphic card) on board to test
 - If the problem is solved with minimum system *hardware*, please add the devices one by one and find out which part is at fault
 - If the problem still remains with minimum system *hardware*, please contact your Service Center
- During Windows LOGO loading
 - If the PC can enter safe mode successfully, please enter OS safe mode and uninstall the newly installed driver or *software*
 - If the PC cannot enter safe mode, please try re-installing the OS. Before re-installing, please back up the important data first.

Power supply does not work well

- Different areas have different voltage supplies, please check the voltage selector on the power supply (115v/230v).
- The power cable works fine: When power is on, the power LED on the motherboard is on:
 - Can *boot* up via the power pin on the motherboard, please check if all the *hardware* devices are connected well.
 - Can't *boot* up via the power pin, please contact your Service Center.
- When power is on, the power LED on the motherboard is still off: If convenient, please test the power supply in another PC which is working fine.

• The power cable is faulty, please change the power cable to check if this might be the problem.

The PC works very slowly

Solution

- Before entering the Operating System
 - Hangs during *POST*, try to determine which device is always being searched when the PC hangs:
 - Take off the unnecessary device to see if that speeds up the PC.
 - Change the *hardware* one by one
- Hangs at the Windows Login
 - · Enter safe mode to see if the issue is still evident
 - Re-install the drivers
 - Re-install a new "clean" Operating System
- · After entering the OS, it takes a long time to see the desktop
 - Click Start"—" Run", input " msconfig", enter" System Configuration Utility"—" Startup", cancel the unnecessary *boot* up items
 - Check if caused by any incompatible *software*
 - Please optimize the system
- Only runs slowly when using some special software
 - Check if the system configuration fulfils the minimum requirement of the software
 - End the process which takes up the most CPU usage
 - Please optimize the system
- Only runs slowly when connect to the internet
 - Change the *network* cable to see if the speed changes
 - Scan for any virus
 - Please optimize the system
- An abnormally high temperature causes the slow speed
 - Check the fan settings in the BIOS
 - Improve the heat transfer conditions
 - Please optimize the system

CPU fan is too noisy

- Check if the CPU fan is damaged and whether the fan is well connected to the motherboard
- Please clean the CPU fan since this problem may be caused by dust. Please put on some CPU lube if necessary
- Please check if the CPU fan always runs at a high speed

- Check if the settings in the *BIOS* is correct
- Please check if the problem only appears when the CPU load is high.

Freezes frequently

Solution

Freeze/ Hang during POST

- If some new *hardware* has been installed, please un-plug the new *hardware* for a test
- If there is no new *hardware* added, please only keep the necessary components to have a check

After POST and before entering OS

- If you could enter safe mode successfully, please enter safe mode to un-install the drivers and the *software*
- If not, please re-install a new clean OS

After entering OS

- Freezes/Hangs frequently and unpredictably
 - If the Temperature is abnormal, please check the CPU temperature and the heat transfer of the chassis.
 - If the temperature is OK, please scan your PC for any virus
- Freezes/Hangs when running certain *application*s or games
 - Please update by loading any new patch available from the corresponding website

Cannot connect to the Internet

- Check the LAN settings in the **BIOS**
- Install a new clean OS and install the chipset and LAN drivers *download* ed from the official website
- The *network* adapter might not be recognized in Device Manager
 - If there is yellow question mark or exclamation mark before the *network* card in the Device Manager, please re-install the OS and drivers. If the problem persists, please contact our service center.
 - If there is no yellow question mark or exclamation mark before the *network* card:
 - In Control Panel/Network Connections/Local Area Connection, the network cable is shown as "un-plugged(X)", please check the network cable/router/switch/modem/other network peripherals and network port, or plug network cable to another system
 - In Control Panel/Network Connections/Local Area Connection is disabled (grey), please enable(right click and choose "Enable") it for a test. If the problem persists, please turn off the *firewall*, search for and kill any *virus*, reinstall the OS and drivers. If the problem still exists, please contact our service center
 - In Control Panel/Network Connections/Local Area Connection is shown as "Limited or no connectivity" (yellow exclamation mark)", please do some troubleshooting using

the following steps:

- Right click and choose "repair"
- Un-plug and re-plug the *network* cable
- Check *server* DHCP settings, IP configuration, seek advice from your *Internet* Service Provider
- Restart
- Re-connect the *network* or access IP
- Skip the router and connect to the Modem directly
- Turn off other computers in the same *network* to avoid any IP conflicts
- There is no abnormal situation in Control Panel/*Network* Connections/Local Area Connection, please do some troubleshooting using the following steps:
 - Try to access the IP or Static IP automatically
 - Un-plug and re-plug the *network* cable
 - Check server DHCP settings, IP configuration, seek advice from ISP
 - Restart
 - Re-connect the *network* or access IP
 - Turn off other computers in the same *network* to avoid any IP conflicts
 - Check the MAC address (You can follow the commands: "Start"—" All Programs"—" Run",
 - Please input " cmd", and then input " ipconfig/all" to check MAC address
 - If the *network* card is not recognized in Device Manager, please contact our service center

4GB of Memory Installed, Computer only Recognizes 3.0GB or less

- If you installed a total of 4GB of *memory*, the system will detect less than 4GB of total *memory* because of address space allocation for other critical functions, such as:
 - System *BIOS* (including motherboard, add-on cards, etc...)
 - Motherboards resources
 - Memory mapped I/O
 - configuration for AGP/PCI-Ex/PCI
 - Other memory allocations for PCI devices
- Different onboard devices and different add-on cards (devices) will result in a different total memory size.
 - e.g. more PCI cards installed will require more *memory* resources, resulting in less free *memory* for other uses.
- On an SLI system, since PCI Express graphic cards will occupy around 256MB, another 256MB will be occupied after you install a 2nd PCI Express graphic card. Hence, only 2.75GB of memory is left

if two SLI cards are installed while 3.0GB *memory* is left with one graphic card.

- This limitation applies to most chipsets and to Microsoft Windows 32-bit version operating systems.
- With a Windows 32-bit version of the *operating system*, we recommend that you have less than 3GB of total *memory* installed. If more than 3GB *memory* is required for your system, then these two conditions must be met:
 - The *memory* controller which supports *memory* swap functionality must used. Chipsets later than Intel 975X, 955X, Nvidia NF4 SLI Intel Edition, Nvidia NF4 SLI X16, and AMD K8 CPU architecture support *memory* swap function.
 - 2. Installation of a Windows 64-bit *Operating System*, which can address more than 4GB of *memory*.

Audio is abnormal

Solution

Abnormal input/output

- There is a yellow question mark before the audio device in Device Manager
 - First please install the patch "MICROSOFT UAA Function Driver for High Definition Audio" for the *Operating System*
 - Re-install the audio driver
- There is a yellow exclamation mark before the audio device in Device Manager
 - First un-install all the drivers related to the audio device and install the patch "MICROSOFT UAA Function Driver for High Definition Audio" for the *Operating System*
 - Restart the PC, if the problem still persists, please recover the system or re-install the Operating System and load the latest audio device driver
- The audio device could not be recognized in Device Manager
 - Load the default **BIOS**, making sure the onboard audio function is enabled in **BIOS**
 - Re-install a new clean Operating System
- No output or input from the rear panel
 - Adjust the audio settings in the Control Panel
 - Update the Audio driver
 - Change the Audio device, such as the microphone, earphone or speaker
- No *output* or input from the front panel
 - Please check if there is any *output*/ input from the rear panel, if not, please do some troubleshooting
 - Change to [AC97] mode in the BIOS (if the front panel module is AC97 compliant)
 - Adjust the audio settings in the control panel
 - Check if the front panel is connected correctly
 - Try swapping for another chassis front panel connector
- Abnormal Sound: Sound is low
 - Adjust the audio settings in the control panel

- Close some sound resources which have not been used for a while, such as SPDI/F, MIC
- Update the audio driver
- Change the Audio device, such as the microphone, earphone or speaker

Sound with Noise:

- If caused by a magnetic field, please move the computer away from the field to see if that is the problem
- Adjust the audio settings in the control panel
- Close some sound resources which have not been used for a while, such as SPDI/F, MIC
- Update the audio driver
- Change the Audio device, such as the microphone, earphone or speaker

How to have dual video output



• Our Desktop PCs commonly support VGA, DVI, DisplayPort and HDMI ports. The display output ports may vary with different models. If you are having issues building dual display output or other problem, please contact our service desk for further troubleshooting. Please make sure to describe the symptom in detail.

- Connect one end of the cables to the two different monitors and the other ends to the video ports on the back of the computer. If the connections of your monitors do not match the video connections of your computer, you may require a cable adapter that allows you to get the video signal to the *monitor*. At the bottom of this page there are photos of the various cables and some popular cable adapters.
- 2. How to set the *output* mode in system:
 - Connect two monitors to your computer and connect the power cords to the monitors for the system to detect automatically. If only one *monitor* receives the signal, please right click on desktop and select Screen resolution.

	View	•
	Sort by	,
	Refresh	
	Paste	
	Paste shortcut	
	Undo Move	Ctrl+Z
	NVIDIA Control Panel	
	New	,
	Screen resolution	
	Gadgets	
2	Personalize	

Select the **Duplicate these displays** in **Multiple displays** scroll down list:



Then it will show the same desktop on your monitors. The maximum resolution is limited by the highest resolution support of your monitors.

If you select "Extend these displays", it will allow you set the resolution of each *monitor* separately.

In this mode, it allows you to show different information on two monitors. Just drag the window out of the current desktop then you will see it in the second desktop.

Display on *Monitor* 1:

Display on *Monitor* 2:



VGA to VGA





HDMI to HDMI



DisplayPort to DisplayPort







BIOS Errors

BIOS errors will cause beeping sounds when the computer is trying to POST. The quantity and duration of the beeps indicate where the error occurs. The following table gives the most common beep patterns.

BIOS Beep	Description	Troubleshooting Techniques
One short beep	No keyboard detected Graphics Card detected	 Plug in keyboard, if not already done. Remove and reinsert keyboard's USB connection to computer. Try plugging keyboard into a different USB port on the system.
Two short beeps	When using <u>Asus</u> <u>Crashfree</u> to recover BIOS, the new BIOS is successfully recognized	• No troubleshooting required.
One continuous beep followed by two short beeps then a pause (repeated)	No RAM memory detected	 Reseat the RAM modules. Try a installing the RAM in different DIMM slots. Try using a different RAM module.
One continuous beep followed by three short beeps	No graphics card or integrated graphics detected	 Ensure that the graphics card is installed and seated correctly in the first PCIe slot. Reseat if needed. Check to see if the graphics card requires extra power directly from the power supply. Refer to Graphics card literature.
One continuous beep followed by four short beeps	Failure of hardware component	• Call Northern Micro for support.

TPM

TPM (Trusted Platform Module) is an integrated chip on the motherboard that stores keys, passwords and digital certificates. It is specifically designed to enhance platform security above-and-beyond the capabilities of today's *software* by providing a protected space for key operations and other security critical tasks. The information stored is typically much more resistant to attacks; both *software* and theft. *TPM* protects encryption and signature keys at their most vulnerable stages i.e operations when the keys are being used unencrypted in plain-text form. Access to data could be denied if the *boot* sequence is not as expected making email, secure web access and data protection much more secure.

Systems with TPMs offer improved, *hardware* -based security in numerous applications, such as file and *folder* encryption, local password management, S-MIME e-mail, VPN and PKI authentication and wireless authentication for 802.1x.

How do TPMs compare with smart cards or biometrics?

Smart cards and/or biometrics are complementary to the *TPM*, which is considered a fixed token that can be used to enhance user authentication, data, communications, and/or platform security. A smart card is a portable token traditionally used to provide more secure authentication for a specific user across multiple systems, while biometrics are providing that functionality in an increasing number of systems. Both technologies can have a role in the design of more secure computing environments.

Can the Trusted Platform Module control what software runs?

No. There is no ability to do this. The subsystem can only act as a 'slave' to higher level services and applications by storing and reporting pre-runtime configuration information. Other applications determine what is done with this information.

How does Microsoft's BitLocker technology relate to the TPM

Microsoft BitLocker^M Drive Encryption is designed to make use of a Trusted Platform Module (*TPM*) 1.2 to protect critical system files and user data and to help ensure that a computer running Windows Vista has not been tampered with while the system was offline.

Is the TPM required for BitLocker?

For BitLockerTM to make use of a *TPM*, it must be a version 1.2. While it is possible to use BitLockerTM without a *TPM* by storing the keying material on a *USB* flash drive, this is not the preferred customer configuration, nor is it expected to be typical usage due to the cost and manageability challenges associated with this mode of use.

Warning of Potential Data Loss

Take precautions to mitigate the chance of data loss. Data encrypted by any program utilizing the Trusted Platform Module (*TPM*) may become inaccessible or unrecoverable if any of the following occurs:

- Lost Password: Loss of any of the passwords associated with the *TPM* will render encrypted data inaccessible. No password recovery is available.
- Hard Drive Failure: In the event of a failure of a hard disk (or other *storage* media) that contains encrypted data, an image of the hard disk (or other *storage* media) must be restored from backup before access to encrypted data may become available. The owner/user should backup the system hard disk on a regular basis.
- **Motherboard Failure:** In the event of a platform failure and/or replacement of the motherboard, recovery procedures may allow migratable keys to be recovered and may restore access to encrypted data. All non-migratable keys and their associated data will be lost.
- Loss of Trusted Platform Module Ownership: Trusted Platform Module Ownership/contents may be cleared (via a *BIOS* switch) to allow for the transfer of a system to a new owner. If *TPM* ownership is cleared, either intentionally or in

Introduction to Environmental Program

Northern Micro, in an effort to become more environmentally conscious has embarked on a number of programs over the years that pertain to environmental stewardship and comply with applicable laws and restrictions. These programs guide the organization to develop products that safely reduce or eliminate environmentally hazardous materials, promote a "reuse and recycle" End of Life Management model and improve energy efficiency.

At Northern Micro we strive for continuous improvement of our environmental system by incorporating the best possible practices through our waste management and IT products recycling initiatives.

We understand that the achievement of reducing the amount of pollution and waste into our natural environment must rely, to a large extent, on each individual member of the corporate team. As such, all employees, with the full support of management, contribute to the goal of reducing, reusing and recycling our products and the waste we produce.

In this regard, Northern Micro also works with committed partners that exhibit a focus on Sustainable Development and Green procurement. The following are some organizations and programs that promote safe Environmental stewardship and in which Northern Micro participates as part of its overall commitment to our environmental policy.

- Electronics Product Stewardship Canada (EPSC)
- Call2Recycle (formerly named Rechargeable Battery Recycling Corporation (RBRC))
- EPEAT (a program of the Green Electronics Council)
- Energy Star, Microsoft WHQL, 80+ and TCO Development.

Environmental policy

"Northern Micro is committed to continually reducing the amount of Pollution created in its manufacturing plant by offering recycling solutions for IT equipment and by properly reducing, reusing and recycling its packaging material. Northern Micro maintains an Environmental Management system that it is proud of and one that complies with all of its legal and other defined environmental requirements."

Environmental Program

ISO14001

Northern Micro is dedicated to providing computer products and services that meet or exceed the quality, operational performance and life cycle cost requirements of our customers. In an effort to continually improve our system we have implemented our Environmental Management System (EMS), which also meets the requirements of the ISO-14001 Environmental Management System. The Environmental Management System assures that NM computer products, their manufacturing, their delivery, and their recycling are processed under the control of the system. The System is designed to adhere to ISO 14001:2004 standard. The system assures conformance to legal and the company's environmental policy and provides objective evidence of effective control. Northern Micro attained its ISO 14001 certification in November 2006.

IEEE1680

The policy focuses on areas which address all stages of the product life cycle. IEEE 1680 is the first U.S. standard to supply environmental guidelines for institutional purchasing decisions involving desktop and laptop computers and monitors. It offers criteria in eight categories - materials selection, environmentally sensitive materials, design for end of life, end-of-life management, energy conservation, product longevity and life-cycle extension, packaging, and corporate performance. IEEE 1680 and its product registration and verification system are part of the Electronic Products Environmental Assessment Tool (EPEAT).

EPEAT

EPEAT is a program of the Green Electronics Council and provides a procurement tool to help institutional purchasers in the public and private sectors evaluate, compare and select desktop computers, notebooks and monitors based on their environmental attributes. EPEAT also provides a clear and consistent set of performance criteria for the design of products, and provides an opportunity for manufacturers to secure market recognition for efforts to reduce the environmental impact of its products. Northern Micro EPEAT certified products are listed on the EPEAT's web site (http://www.epeat.net).

RoHS

RoHS (Reduction of Hazardous Substances) - The reduction and/or elimination of environmentally sensitive materials and hazardous substances. As of July 31st 2005, all Northern Micro systems refreshed on the NMSO (National Master Standing Offer) utilize RoHS compliant components.

Flame retardants and plasticizers - The elimination of intentionally added flame retardants and plasticizers in certain applications.

Recycled plastics content - Ensuring that the product contains *post* consumer recycled plastic <5.0% by="" weight,="" measured="" as="" a="" percentage="" of="" total="" plastic="" (by="" weight)="" in="" each="" product="" or="" does="" not.="" this="" applies="" to="" all="" covered="" products="" that="" contain="" plastics,="" excluding="" pcb="" and="" packaging.

Renewable/bio based plastic materials - A declaration as to whether the product contains renewable/biobased plastic materials greater than 5.0 %, measured as a percentage of total plastic (by weight) in each product.

Toxins in packaging - Ensuring a reduction/elimination of intentionally added toxins in packaging

Other Environmental practices employed by Northern Micro

- Power Management Ensuring maximum efficiency without sacrificing performance in product design.
- Thermal Consideration Ensuring the proper case/motherboard/CPU configuration is developed to maintain the required Thermal levels.
- Acoustic Levels Ensuring systems conform to ISO 9296 declaration methodology and employing the ISO 7779 test methodology for acoustic levels.

Energy Star, Microsoft WHQL and 80 PLUS

- **ENERGY STAR** is a joint program of the U.S. Environmental Protection Agency and the U.S. Department of Energy to help save money and protect the environment through energy efficient products and practices. Northern Micro is an active participant in the Energy Star and certifies its products as Energy Star compliant (as listed on their web site http://www.energystar.gov/)
- The Microsoft WHQL program is used to qualify products that conform to industry standards for computer and related equipment. Among the criteria being measured are Power Management features (Wake On-LAN, ACPI, Sleep/Suspend/Hibernate) which greatly enhance the longevity of key system components, reduce power requirements and offer overall improved efficiency and performance to the user and the environment.
- The **80 PLUS program** is one of the latest power conservation initiatives that promote the maximum operating efficiency of power supplies within computer equipment. The performance specification requires power supplies in computers and servers to be 80% or greater energy efficient at 20%, 50% and 100% of rated load with a true power factor of 0.9 or greater.
- **TCO Development** ensures that certified products are tested to conform to standards developed by them and which create a better working environment for office users. Northern Micro uses TCO '03 certified LCD *monitor* products from its partners.

EPSC

The EPSC (http://www.epsc.ca) is a not-for-profit organization and works with an array of partners and stakeholders to design, promote and implement sustainable solutions for Canada's electronic waste problem. These industry leaders are aware of both the pressures on municipalities for landfill management and the environmental necessity to handle the potentially hazardous content of electronics products and reuse the valuable resources they contain. EPS Canada was created to work with both industry and government to develop a flexible, workable Canadian solution. Northern Micro is an active member of the EPSC. The EPSC has recognized both Environment Canada's ECO Logo and the corresponding US EPEAT programs as tools for developing environmentally friendly solutions.

Call2Recycle (formerly RBRC)

Call2Recycle (https://www.call2recycle.ca), through their North American wide program recycles used portable rechargeable batteries and old cell phones typically found in cordless power tools, cellular and cordless phones, laptop computers, camcorders, digital cameras, and remote control toys. Call2Recycle recycles the battery chemistries: Nickel Cadmium (Ni-Cd), Nickel Metal Hydride (Ni-MH), Lithium Ion (Li-ion) and Small Sealed Lead (Pb). Call2Recycle is dedicated to keeping rechargeable batteries and cell phones out of our nation's solid waste stream and preserving natural resources. Northern Micro participates in the Call2Recycle program and accepts without charge all batteries meeting the above specifications, regardless of when and through whom they were purchased.

Electrostatic Discharge (ESD)

Short for electrostatic discharge: the rapid discharge of static electricity from one conductor to another of a different potential.

Static Electricity: Creating Charge

Under certain conditions (low humidity, carpeted floors, etc. static electricity will build up. Contact with these sensitive components may cause the build-up to discharge into the integrated circuitry of the component; a powerful enough discharge may damage or destroy the component.

Electrostatic discharge can change the electrical characteristics of a semiconductor device, degrading or destroying it. Electrostatic discharge also may upset the normal operation of an electronic system, causing premature equipment malfunction or failure.

Static Electricity Precautions

To protect components against damage from static electric discharge, you should follow some basic precautions whenever you handle them:

- Use a grounding wrist strap. The strap will have an 'alligator' clip at the end of a shielded wire lead. Clip it to a grounded object. Any static electricity will then harmlessly discharge through the strap. Put on and connect the strap before you handle the components.
- Use an anti-static pad. Put any components on the pad whenever you work on them outside the computer. If you don't have a pad, put the components on the anti-static bag they came in.



• Both the wrist strap and pad are inexpensive and are generally available from computer supply companies.

Location and Electrical Service

- Position your system unit, *monitor* and cables/wires away from direct sunlight, moisture, dust, oil and thoroughfares.
- Do not submit your equipment to harsh jarring.
- Ensure that all ventilation outlets are always free from obstruction.
- In the event of mechanical/power failure or damage, do not attempt to repair the system unit, *monitor*/s or cables/wires. Refer all such problems to experienced service personnel.
- Ensure that the back of the system unit is at least 3 inches away from anything that might obstruct the ventilation outlets and cause over-heating.
- Ensure that the power source is grounded correctly. This product is equipped with a 3-wire grounding-type plug. This plug will only fit into a grounded power outlet.

L

• It is recommended not to service this product yourself, as opening and removing covers exposes dangerous voltage areas and other risks. Refer all servicing to service persons.

Cleaning / Moving Your Computer

The Computer:

- Keep it in a dry, clean space and stand it on a flat surface
- Minimize exposure to dust don't get the power switches or other controls wet
- If you move it from a very cold environment to a warm environment, give the components time to reach room temperature before switching them on
- Use a mild cleaning solution (no detergents!) and a damp cloth to clean exterior surfaces
- Occasionally remove dust from interior surfaces, taking care not to touch or damage connections or chips

The keyboard:

- Keep food and drinks away from the keyboard
- Use a mild cleaning solution and a damp cloth to clean exterior surfaces

The monitor :

- Don't touch the screen with hard objects such as pens and pencils
- Remove dust from the surface by blowing it or wiping it gently with a dry cloth; then use a soft cloth with nonabrasive liquid glass cleaner
- Check cleaner instructions to be sure that it is safe for glass

The mouse :

• When your *mouse* doesn't obey you, it's time to clean it, use a mild cleaning solution (no detergents!) and a damp cloth to clean exterior surfaces.

Moving the computer:

- It's possible to damage data on the hard disk when you move your computer, so you should back up all critical data first. Remove all data disks from the drives. Turn off the computer and all peripherals. Unplug the power cord and disconnect all cables. If you aren't familiar with the panel setup on your computer, sketch the location of cables first.
- Pack the computer and peripherals in well-cushioned packing cartons, preferably the original boxes.

Information Backup

It's wise to make backup copies of your original *software* in the event that the original is damaged. For the same reason, you should frequently back up important data while you are working. Save your work to the hard disk regularly (some programs do this automatically or offer auto backup as an option). More importantly, save the data to a backup such as a tape drive, disc or removable hard disk several times during each work session. If your hard disk crashes or a power failure destroys your file or your office is broken into, you will be thankful you did.

If your data is critical, it's advisable to make a second backup and keep this in a fireproof safe or a safe location out of the office.

Hard Drive Maintenance

Traditional Hard Disks

Traditional hard disks are a rigid magnetic-sensitive disk mounted on a single spindle. Each disk has one or two read and write heads (for one or both sides), which float above the surface of the disk. The disk spins at a constant rate, and the heads move across the surface to locate information as required.

Each disk is segmented into tracks, which are themselves divided into sectors. The address of a piece of information includes both the track and sector.

Fragmented files

After storing and removing many pieces of data, the hard disk can get fragmented — information for the same file may be scattered everywhere. When you call up that file, the heads must move many times back and forth to recall the information. Defragmenting the disk puts these pieces back together and gets your computer running fast again .

Your *operating system* may offer a feature to consolidate your disk. There are also several programs available that examine and, if necessary, defragment the disk.

Solid State Disks

Solid State disks (SSD) are a data *storage* device using integrated circuit assemblies as *memory* to store data persistently. SSD technology uses electronic interfaces compatible with traditional hard disk drives. SSDs have no moving mechanical components, using flash *memory* instead of magnetic disks. They can be used in place of traditional magnetic hard disk drives or along side traditional drives for more *storage* or as a faster way to *boot* the computer.

Erased files

Regardless of whether you have a magnetic drive or a solid state drive, if you have erased a file by mistake, most operating systems offer an undelete or restore feature to recover some or all of your material. The more work you do on the computer after deleting the program, the lower the probability of full recovery.

The fact that erased files remain on the disk may be a concern for some security applications. If security-sensitive information is erased and the computer or diskette passes to another person, security may be breached. To prevent this from happening, you can do a low-level format on a hard drive , or reformat a diskette. Programs for low-level *operating system* formats are readily available.

Passwords

A power-on password locks the keyboard and *mouse* to prevent unauthorized people from using your computer. When the computer is turned on, it prompts the user for a password. Entering the correct password unlocks the keyboard and *mouse*.

Another option is to set a supervisor password, which restricts access to the setup utility only. This is critical because passwords can be disabled through the setup. Make sure you store your password in a secure place. If you forget your supervisor password, you will have to remove your battery and reconfigure your computer to get it working again.

Computer Viruses

Like viruses that infect humans, a computer *virus* contains instructions for its own proliferation and is potentially very harmful. Though some computer viruses are just playful, most are dangerous for your computer and data. For example, some viruses destroy the file allocation tables, so that your computer cannot locate files or *software*. Some viruses are programmed to become active on a certain date (e.g. April 1 or Friday 13) or when you execute a certain command.

Programs are available that scan diskettes and hard drives for viruses. Some of these programs will also remove the *virus*. These programs can be set to test the computer for viruses every time you power up. To protect your computer from viruses, you should also scan every outside disk before using it. Write-protect your *software* diskettes so that they cannot be infected. Avoid programs and diskettes from unknown sources. Only buy *software* in sealed packages.

Networks, the *Internet* and bulletin board services represent special risks. Use only well known electronic bulletin boards. If you plan to *download software* from the bulletin board, ask the service what steps it is taking to guard against viruses.

If your computer is behaving erratically, it may be infected by a *virus*. Check out the problem before proceeding further.

There are more than 100,000 known viruses out there. Although there are thousands of viruses identified each year, there are still some that only exist in the imaginations (*virus* hoax) of the public and the press.

System Safety

Electrical Safety

Electric current from power, telephone and communications cables can be hazardous. To avoid any shock hazard, disconnect all power cords and cables as described below:

Before removing the cover:

- Turn off the computer and all peripherals, such as monitors, printers and external devices.
- Unplug all power cords from electrical outlets.
- Disconnect all communications cords from external receptacles.
- Disconnect all cables and power cords from the back panel of the computer.
- Never remove the power supply cover. If you suspect a problem with this part, call Northern Micro service at 613-226-1117.

Re-configuring

- To keep the computer from being damaged, NEVER reconfigure the board while the power is ON.
- If you wish to reconfigure the computer at any time, ensure that the power is turned OFF before changing any *hardware* settings, such as DIP switches or jumpers.



• Risk of explosion if battery is replaced by an incorrect type. Dispose of batteries according to the manufacturer's instructions.

Monitor Safety Instructions

- Never insert anything metallic into the *monitor* openings. Doing so may create the danger of electric shock.
- To avoid electric shock, never touch the inside of the *monitor*. Only a qualified technician should open the monitor's case.
- Never use your *monitor* if the power cord has been damaged. Do not allow anything to rest on the power cord, and keep the cord away from areas where people can trip over it.
- Be sure to hold the plug, not the cord, when disconnecting the *monitor* from an electric socket.
- Openings in the *monitor* cabinet are provided for ventilation. To prevent overheating, these openings should not be blocked or covered. Also, avoid using the *monitor* on a bed, sofa, rug, or other soft surface. Doing so may block the ventilation openings in the bottom of the cabinet. If you put the *monitor* in a bookcase or some other enclosed space, be sure to provide adequate ventilation.
- Put your *monitor* in a location with low humidity and a minimum of dust.
- Do not expose the *monitor* to rain or use it near water. If the *monitor* accidentally gets wet, unplug it and contact an authorized dealer immediately. You can clean the *monitor* with a damp cloth when necessary, but be sure to unplug the *monitor* first.
- Place the *monitor* on a solid surface and treat it carefully. The screen is made of glass and can be damaged if dropped, hit or scratched.
- Locate your *monitor* near an easily accessible AC outlet.
- If your *monitor* does not operate normally, in particular, if there are any unusual sounds or smells coming from it, unplug it immediately and contact a service center.
- High temperatures can cause problems. Do not use your *monitor* in direct sunlight; keep it away from heaters and other sources of heat.
- Unplug the *monitor* when it is going to be left unused for an extended period of time.
- Unplug your *monitor* from the AC outlet before any service.



• To reduce the risk of electric shock, do not remove cover (or back). No user-serviceable parts inside. Refer servicing to qualified service personnel.
DOC Requirements

1		/
/	χ.	1
<u> </u>	-	_

- A shielded power cord is required to meet ICES-003 emission limits and also to prevent interference to nearby radio and television reception. It is essential that only the attached power cord be used.
- Use only shielded cables to connect I/O devices to this computer.
- You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment. This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the radio interference regulations of Industry Canada.

This equipment has been tested and found to comply with the Industry Canada ICES-003, Issue 2 Rev. 1, Digital Apparatus, Class B requirement. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warranty Policy

Limited Warranty: All Northern Micro products shall be free from defects in materials and workmanship at the time of original sale by Northern Micro. All Northern Micro products are in accordance with our published specifications or those specifications agreed to by Northern Micro and the purchaser at the time of original sale.

Warranty Period: Any Warranty Period purchased from Northern Micro is from the date of Customer purchase of the product. All defects must be reported to Northern Micro during the Warranty Period.

Warranty Rights: For any product found to be defective, and reported to Northern Micro to be defective within the Warranty Period, Northern Micro, at its option, will repair or replace the defective product. Any repaired or replaced product will assume the remaining warranty coverage or will be covered for ninety (90) days from the date of repair or exchange, whichever is longer.

Exclusions From Warranty: Any improper installation or use, operation beyond capacity, accidents not attributable to Northern Micro, substitution of parts not approved by Northern Micro or any alteration or repair by others in such manner as in Northern Micro's judgment affects the product materially and adversely shall void this Limited Warranty.

Limitation of Remedies: Northern Micro's obligation for defective product is limited to repairing or replacing the product, or parts thereof, as expressly stated in this Limited Warranty. In no event shall Northern Micro be liable for any direct, indirect, incidental, consequential, or special damages arising out of the operation, or failure of operation, of the product. Northern Micro shall not be liable for any costs of procurement of substitute goods, loss of profits, personnel costs, payments to third parties, or any consequential, incidental, and/or other damages of any kind resulting from a breach of any applicable express or implied warranty, or otherwise with respect to the sale of any Northern Micro product.

Exclusion of Other Warranties: The above Limited Warranty constitutes the sole and exclusive warranty and remedy with respect to any defective Northern Micro product and is in lieu of all other obligations or liabilities of Northern Micro. All other warranties, expressed or implied are hereby disclaimed, including but not limited to any warranty of merchantability or fitness for any particular purpose. Northern Micro's liability, whether based on contract, warranty, strict liability, tort, or any other basis, shall not exceed the price of the product whose defect or damage is the basis of the claim.